



EXCELL PRECISION CO. LTD.

EXCELL®

# Dingo

## EX2002

# OPERATION MANUAL

© Excell Precision Limited 2003. All rights reserved Worldwide.

The information contained herein is the property of Excell Precision Limited and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorised by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.




Safety .....	3
Features .....	3
<b>CHAPTER 1 FRONT AND REAR PANEL SPECIFICATIONS .....</b>	<b>3</b>
1-1 Front panel.....	3
1-2 Rear panel.....	3
1-3 Keyboard description .....	3
1-4 A/D Conversion .....	3
1-5 Power supply.....	3
1-6 Dimensions.....	3
<b>CHAPTER 2 GENERAL FUNCTION GUIDE .....</b>	<b>3</b>
2-1 Function setup and operation procedures .....	3
2-2 Function setting  .....	3
<b>CHAPTER 3 CALIBRATION.....</b>	<b>3</b>
3-1 Load cell connection .....	3
3-2 Parameter setting and calibration flow chart .....	3
3-3 Specification calibration  .....	3
3-4 General Calibration  .....	3
3-5 Linearity calibration  .....	3
3-6 Digital calibration  .....	3
3-7 Calibration Error Messages .....	3
<b>CHAPTER 4 WEIGHT COMPARISON PROCEDURES .....</b>	<b>3</b>
4-1 Function configuration menu.....	3
4-2 Check weighing configuration .....	3
4-3 Batching signal outputs .....	3
4-4 Normal batching flow chart (SQ-01=1) .....	3
4-5 Loss-in Weight flow chart ( SQ1 = 2 ) .....	3
4-6 Hi, OK, Lo output flow chart.....	3
4-7 Normal batching (built-in program) flow chart (SQ-01=4) .....	3
4-8 Loss-in Weight (built in program) (SQ-01=5) .....	3
4-9 Hold mode (SQ-01 = 6).....	3
4-9-1 Hold mode flow chart .....	3
4-9-2 Hi, OK, Lo comparison .....	3
4-10 Totalizing (ACCU.) Auto / Transmit .....	3
<b>CHAPTER 5 INTERFACE.....</b>	<b>3</b>
5-1 Serial input/output interface (default OP-01) .....	3
5-2 BCD parallel output interface (OP-02)  .....	3
5-3 Analogue Current / Voltage Output Interface (OP-03) .....	3
5-4 External parallel input / output interface.....	3



<b>CHAPTER 6 MAINTENANCE.....</b>	<b>3</b>
<b>6-1 Restore all parameters to their default factory values.....</b>	<b>3</b>
<b>6-2 Maintenance function parameters .....</b>	<b>3</b>
<b>6-2-1 Restore the function parameter back to its default value. ....</b>	<b>3</b>
<b>6-2-1 Restore the function parameter back to its default value. ....</b>	<b>3</b>
<b>6-2-2 Clear zero compensation and TARE values .....</b>	<b>3</b>
<b>6-2-3 Clear batch setting .....</b>	<b>3</b>
<b>6-2-4 Display zero voltage (mV/V).....</b>	<b>3</b>
<b>6-2-5 Clear batch setting .....</b>	<b>3</b>
<b>6-3 Test mode .....</b>	<b>3</b>
<b>6-3-1 7 segment display testing .....</b>	<b>3</b>
<b>6-3-2 Keypad and calibration SW testing.....</b>	<b>3</b>
<b>6-3-3 Display A/D internal value display.....</b>	<b>3</b>
<b>6-3-4 RS-232 serial loop back testing.....</b>	<b>3</b>
<b>6-3-5 EEPROM memory testing.....</b>	<b>3</b>
<b>6-3-6 Option interface card testing .....</b>	<b>3</b>
<b>APPENDIX I Description of 7 segment characters .....</b>	<b>3</b>
<b>APPENDIX II Function Table.....</b>	<b>3</b>



## Safety

- 
- A large gray triangle is positioned in the center of the page. Inside the triangle is a white exclamation mark symbol, indicating a warning or important safety information.
- 2 When the instrument is installed, connect an earth bonding conductor from FG to the earth connection marked “  $\pm$  ”.
  - 2 Disconnect the mains power supply before opening the instrument housing. NOTE: There are no user serviceable parts inside.
  - 2 To install the optional interface cards, it is necessary to disconnect the mains power supply and fit a yellow/green earth bonding cable to the rear panel.
  - 2 Before turning the power on ensure the supply voltage is within the acceptable range, AC85V ~ AC265V.
  - 2 The operating ambient temperature range is -10°C ~ +40°C.  
(+14°F ~ +104°F)



## Features

EX2002 Dingo has a wide range of applications from batching to simple weighing.

### Features:

Stand alone batching mode or connect to PLC for external system control

Built in batching / dosing functions

Manual / automatic discharge operation

Set cycle times in a batch

Totalise weight and number of cycles

Key in the signal voltage value (mV/V) directly via the keyboard, no need to apply any weight to the bottomwork to calibrate the weigher.

Display load cell output voltage (mV/V) for future maintenance

Adjustable filter

RS232C bi-directional and current loop one way serial interface

### Interface options:

OP-01 RS422/485/232 serial interface

OP-02-1 BCD parallel output interface (Open collector output)

OP-02-2 BCD parallel output interface (TTL output)

OP-03 16 Bit Analogue current/voltage output interface  
(4 ~ 20 mA / 0 ~ 10V)

OP-04 Control I/O (4In / 4Out) + Setpoint In (BCD code)


OP-05 Control I/O (8In / 8Out)



# CHAPTER 1 FRONT AND REAR PANEL SPECIFICATIONS

## 1-1 Front panel

◆



### Display

- 6 digits, bright red, 7 segment LED display, character height 16mm (0.63").  
Display can be switched between Gross Weight / Net Weight / Totalised Weight / Number of transactions in the total.

- Indication icons “◀”

ZERO	◀	: Zero Indication
MD	◀	: Unstable weight Indication
GROSS	◀	: Gross weight Indication
NET	◀	: Net weight Indication


- ◆ The indicator is supplied with suitable labels to customise the icon displays. Refer to FNC. 06 ~ FNC.09 for the various options available.

## 2 Weighing Units

- ◆ Weighing Units kg / g / t / lb.



## 1-2 Rear panel



2 Calibration Switch set to the left is "OFF" and to the right is "ON"

2 13 Way Terminal Block


- 1<sup>st</sup> : EARTH or GROUND
- 2<sup>nd</sup> : AC IN
- 3<sup>rd</sup> : AC IN
- 4<sup>th</sup> : Not Used
- 5<sup>th</sup> : Serial Current loop out
- 6<sup>th</sup> : Serial Current loop out
- 7<sup>th</sup> : RS232 TXD
- 8<sup>th</sup> : RS232 RXD
- 9<sup>th</sup> : RS232 SG
- 10<sup>th</sup> : EXCITATION +
- 11<sup>th</sup> : EXCITATION -
- 12<sup>th</sup> : SIGNAL +
- 13<sup>th</sup> : SIGNAL -




## 1-3 Keyboard description




- When entering data or reference setting, it means "ESC".  
In the normal operation, it puts the indicator in standby mode or escape.  
: Entering standby mode: All of the display (except ZERO "3" symbol) and serial data output are disabled.  
Escape from standby mode: Re-power on mains for normal operation.



- : When parameter setting, it moves the flashing digit left.  
: In the normal mode, it performs a Zero operation.




- : When parameter setting, it moves the flashing digit right.  
: In the normal mode, it performs a semi-auto Tare operation.



- When parameter setting, it increments the flashing digit or steps up the  
: select item.  
In the normal mode, it accesses the FNC-05 setting.



- When parameter setting, it decrements the flashing digit or steps down  
the select item.  
In the normal mode, it accesses the FNC-04 setting.



- : Confirm / enter key

### 4 Function FNC-03 can be used to selectively disable individual keys.

- ( ) Zero operation, will be limited by functions CSP-05 and CSP-10.  
( ) Zero operation, will be limited by functions CSP-10 and CSP-11.

## 1-4 A/D Conversion





(Input Sensitivity	: Over 0.12(V/D
(Internal Resolution	: 1 / 1,000,000
(Max. Sampling Speed	: 120 times/sec.
(Application Range	: - 0.1 mV/V ~ 4.0 mV/V
(Load Cell Excitation Voltage	: 5 VDC (5%, 120mA (Up to eight (8) 350 Ω load cells can be connected)

## 1-5 Power supply

- ◆ AC 85V ~ 265V 50/60Hz



## 1-6 Dimensions

**Panel Cutout**



# CHAPTER 2 GENERAL FUNCTION GUIDE

## 2-1 Function setup and operation procedures

Function	Operation	Display	Description
Enter calibration mode	Turn the calibration switch to "ON"	00 000	See 3-2 for details
Enter function setting	Press  and  not release, then press  key after the power is turned on	00 000	See 2-2 for details
Reset all parameters back to default	Turn the power on then turn the calibration switch to "ON" then press and hold the  and  keys during the self-testing sequence	0000	See 6-1 for details
Reset general function parameters back to default	Turn the power on and press  and  keys during self-testing sequence	0 000	See 6-2-1 for details
Clear zero point compensation	Turn the power on and press  and  keys during self-testing sequence	0 0000	See 6-2-2 for details
Clear setpoint parameter setting	Turn the power on and press  and  keys during self-testing sequence	0 000	See 6-2-3 for details
Value of zero point voltage(mV/V)	Turn the power on and Press  and , then press  third times.	0 0000	See 6-2-4 for details
Value of Span voltage (mV/V)	Turn the power on and Press  and  then Press	0 0000	See 6-2-5 for details
Entering to test mode	Turn the power on and press  and  keys during self-testing sequence	0 000	See 6-3 for details
Check weighing setpoint parameter setting	Press the  key to set the parameter of FUNC.4 to 1 in the normal mode	00000 or 0000	See 4-2 for details



## 4 Key actions in function set up mode


-  ⇒ Increases the number of the flashing digit
-  ⇒ Decreases the number of the flashing digit
-  ⇒ Moves the flashing digit one space to the left
-  ⇒ Moves the flashing digit one space to the right
-  ⇒ Saves the configuration
-  ⇒ Quits set up mode / Escape



## 4 Function Setting Procedures



## 2-2 Function setting 8 8 8 8 8



\*Function Parameter code

- |        |   |
|--------|---|
| 888801 | ⇒ Digital Filter I                            |
| 888802 | ⇒ Digital Filter II                           |
| 888803 | ⇒ Lock keypad function                        |
| 888804 | ⇒ "F" function setting                        |
| 888805 | ⇒ "F1" function setting                       |
| 888806 | ⇒ Front panel indication "◀" setting (first)  |
| 888807 | ⇒ Front panel indication "◀" setting(second)  |
| 888808 | ⇒ Front panel indication "◀" setting (third)  |
| 888809 | ⇒ Front panel indication "◀" setting (fourth) |
| 888810 | ⇒ Terms of back to zero                       |
| 888811 | ⇒ Hold  |

To continue the next function setting

or press **I/O  
ESC** to escape

<b>F1 ^</b>	⇒ Increment flashing digit
<b>F ▼</b>	⇒ Decrement flashing digit
<b>→0← ZERO &lt;</b>	⇒ Move flashing point left.
<b>→T← TARE &gt;</b>	⇒ Move flashing point right
<b>⌂ ENTER</b>	⇒ Store data in memory
<b>I/O ESC</b>	⇒ Exit / Escape



## 2 FNC Group function setting

Item	Function	Setting value		Default	
		Parameter	Description		
FNC-01	Digital Filter I	0	5 Hz	4	
		1	4.17 Hz		
		2	2.5 Hz		
		3	2.08 Hz		
		4	1.25 Hz		
		5	1.04 Hz		
		6	0.63 Hz		
		7	0.52 Hz		
		8	0.31 Hz		
		9	0.26 Hz		
FNC-02	Digital Filter II	0	Disabled	2	
		1	Less filter		
		2			
		3			
		4			
		5	Greater		
FNC-03	Key – Locked	000000 ↓ 111111	Normal (lock disable) Close (lock enable)	The bits and front panel key positions are related to each other. 000000	
FNC-04	“F” function setting	Parameter ⇒ Description 0 ⇒ Display Net / Gross weight 1 ⇒ Setpoint parameter setting 2 ⇒ Tare reset 3 ⇒ Manual serial, parallel print output. 4 ⇒ Start load 5 ⇒ Stop load 6 ⇒ Start comparison 7 ⇒ Unload command 8 ⇒ Totalise weight and counts command 9 ⇒ Clear totalised weight and counts 10 ⇒ Hold mode 11 ⇒ Escape Hold mode(I/O DSP) 12 ⇒ Convert to Gross / Net / totalised weight / totalised Count			
FNC-05	“F1” function setting				




Item	Function	Setting value		Default
		Parameter	Description	
FNC-06	Front panel indication “◀” setting (top)	Parameter ⇒ Description 0 ⇒ Zero 1 ⇒ MD 2 ⇒ Gross 3 ⇒ Net 4 ⇒ Totalised weight (Accu. V) 5 ⇒ Totalised transactions (Accu. C) 6 ⇒ SP1 7 ⇒ SP2 8 ⇒ SP3 9 ⇒ Hi 10 ⇒ OK 11 ⇒ Lo 12 ⇒ Under 13 ⇒ Over 14 ⇒ Discharge 15 ⇒ Running 16 ⇒ Hold		0
FNC-07	Front panel indication “◀” setting (next to top)			1
FNC-08	Front panel indication “◀” setting (next to bottom)			2
FNC-09	Front panel indication “◀” setting (bottom)			3
FNC-10	Return to zero band	0 1 2 3 4 5 6 7 8 9	5 d 10 d 20 d 40 d 60 d 80 d 100 d 150 d 200 d 250 d	0
FNC-11	Hold	0 1 2 3	Hold Peak hold (positive) Peak hold (negative) Peak hold (absolute value)	0
FNC-12	Rate for display rewrite	0 1 2 3 4	No limitation 20 times/sec 10 times/sec 5 times/sec 1 time/sec	0



## CHAPTER 3 CALIBRATION


### 3-1 Load cell connection

- 2 When using a 6 wire cable to connect the load cell, the SEN+ and SEN- can be left unconnected (see below diagram)






## 3-2 Parameter setting and calibration flow chart






## 2 Calibration process



- 4 Before the Linearity Calibration, the General Calibration should be completed.



### 3-3 Specification calibration 88888



To continue the next function setting

or press to escape

\*Calibration parameter code

898888 ⇒ Unit

898888 ⇒ Decimal Point

898888 ⇒ Min. Division

898888 ⇒ Max. Capacity

898888 ⇒ Zero Range

898888 ⇒ Time of Zero tracking

898888 ⇒ Range of Zero tracking

898888 ⇒ Investigate period of unstable

898888 ⇒ Investigate range of unstable

898888 ⇒ Function Zero and Tare when the weight is unstable.

898888 ⇒ Tare function availability when gross weight is negative.

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



Item	Function	Setting value		Default
		Parameter	Description	
CSP-01	Unit	0	None	2
		1	g	
		2	Kg	
		3	t	
		4	lb	
CSP-02	Decimal Point	0	None	0
		1	1 Decimal Point	
		2	2 Decimal Point	
		3	3 Decimal Point	
CSP-03	Division	1	Division size	1
		2		
		5		
		10		
		20		
		50		
CSP-04	Max. Capacity	999999 ↓ 000000	Max. capacity	999999
CSP-05	Zero range	0 =full range (±1%~30%)	Zero range = calibration zero point ± (Max. capacity×setting value %)	0
CSP-06	Time of zero tracking	0.0 ~ 5.0 (sec)	Time and range of zero tracking should be use at the same time. If the time is set to 0.0, the zero tracking function is disabled.	1.0
CSP-07	Range of zero tracking	0 ~ 9	Range of zero tracking = (setting value×½)D , D=min. division Range and time of zero tracking should be use at the same time. If the range is set to 0, the zero tracking function is disabled.	2
CSP-08	Investigate time in stable	0.0 ~ 5.0 (sec)	Investigate time and range should be use at the same time. If the time is set to 0.0, the investigate time is disabled.	1.0
CSP-09	Investigate range in stable	0 ~ 9	Investigate time and range should be use at the same time. If the range is set to 0, the investigate range is disabled.	2
CSP-10	Weight unstable, function ZERO and TARE	0	Action	0
		1	None	
CSP-11	Gross Weight is negative, function TARE	0	Action	0
		1	None	



## 3-4 General Calibration 88888

Set CAL switch to ON

88 888

Select General Calibration

88 888

Press the Key

8888 kg

Zero Calibration

No weight on the platform or in the hopper

Press the key

... . . . . kg

Five sec. later

8888

Two sec. later

88888 kg

### Weight Calibration

Use the front panel to key in the weight value

Place the weight on the platform or inside the hopper.

After the weight is stable

Press the key

... . . . . kg

Five sec. later

88 888

Calibration complete set calibration switch to the OFF position

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

- 4 Zero calibration only, press key to escape after the display shows 88888.
- 4 Span calibration only, press key entering directly to span calibration after the display shows 88888.
- 4 Please refer to error message during calibration of the display show 888.X



## 3-5 Linearity calibration 8 8 8 8

\*\* Before the Linearity calibration, the General calibration should be completed.

Set CAL switch to ON

8 8 8 8

Select linearity calibration

8 8 8 8

Press the Key

8.88888 kg

### First linearisation point (is zero)

Ensure there is no weight on the platform or in the hopper.

Press the Key

. . . . >< kg

Five sec. later

2.88888 kg

Two sec. later

000000 kg

### Second linearisation point

Load the platform or hopper with the linearisation weight. Use the front panel to enter the weight value. When the weight is stable

Press the Key

. . . . >< kg

Five sec. later

3.88888 kg

Two sec. later

000000 kg

### Third linearisation point

Load the platform or hopper with the next linearisation weight. Use the front panel to enter the weight value. When the weight is stable

Press the Key

. . . . >< kg

Five sec. later

4 Please refer to the error message list if the display shows 8 8 8 X

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



Continue linearisation

Two sec. later

**Fourth linearisation point**

Load the platform or hopper with the next linearisation weight. Use the front panel to enter the weight value. When the weight is stable

Press the Key

Five sec. later

Two sec. later

**Fifth linearisation point (usually full load)**

Load the platform or hopper with the last linearisation weight. Use the front panel to enter the weight value. When the weight is stable

Press the Key

Five sec. later

Linearisation completed set calibration switch to the OFF position

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

**4** Please refer to the error message list if the display shows



### 3-6 Digital calibration

Set CAL switch to ON

89 888

Select Digital calibration

89 888

Press the Key

8888

Two sec. later

000000

Method 1  
Input zero voltage

0.000036

Method 2  
With no weight on the platform or in the hopper  
press the Key to set zero.

Press the Key

8888

Two sec. later

000000

Input the span voltage

2.90000

Press the Key

888.

Two sec. later

000000

Enter the weighing capacity

030000


Press the Key

89 888

Calibration completed set calibration switch to the OFF position

4 Please refer to the error message list if the display shows 888.X

#### Example:



Zero Voltage ▷ 0.00036 mV/V (incl. dead load)

Span Voltage ▷ 2.90000 mV/V

Capacity ▷ 30000 divisions

Zero voltage calibration.

Span voltage calibration

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape




### 3-7 Calibration Error Messages

- 8 8 8. 0 ⇒ Load Cell output voltage < - 0.1mV/V or > 4mV/V
- 8 8 8. 8 ⇒ Weight value ≤ previous weight value
- 8 8 8. 2 ⇒ Actual measured weight value ≤ previous weight value
- 8 8 8. 3 ⇒ Setting value 0
- 8 8 8. 4 ⇒ mV/V value entered > measuring range
- 8 8 8. 5 ⇒ mV/V value entered is too small (SPAN – Zero < 0 mV/V)
- 8 8 8. 6 ⇒ Displayed resolution is less than 0.12 $\mu$ V / division



# CHAPTER 4 WEIGHT COMPARISON PROCEDURES

## 4-1 Function configuration menu





\* See SQ-XX table below for details of each menu

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



## Functional Parameter Instruction

Item	Function	Setting value		Default
		Parameter	Description	
SQ- 01	Batching mode	1	Normal batch	1
		2	Loss-in weight	
		3	Comparison mode	
		4	Normal batch (Built-in program)	
		5	Loss-in weight (Built-in program)	
		6	Hold mode (Built-in program)	
SQ- 02	Batching start delay time	0.0 ~ 25.5 (sec)	The built-in auto-program starts the batch comparison procedure after the input of the batch start signal.	0.0
SQ- 03	SP1,SP2 Waiting time comparison	0.0 ~ 25.5 (sec)	No full flow comparison during this function's set time period. If the set value is 0, indicates this function is not in use.	0.0
SQ- 04	Batch finish output signal delay time	0.0 ~ 25.5 (sec)	Output the batch finished signal after this delay time.	0.5
SQ- 05	Batch finish Condition	0	Wait until the weight is stabilized	0
		1	No need to wait until the weight has stabilized	
SQ- 06	Batch finish Output signal time	0.0 ~ 25.5 (sec)	Batch finished output signal time. If set to 0, the output signal will be off until the next batch start.	1.0
<b>Batch finish signal</b> 				
SQ- 07	Number of Times the supplementary loading function operates	0 ~ 255	If the set value is 0, this function is not in use.	0
SQ- 08	Supplementary loading gate open time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	0.1
SQ- 09	Supplementary loading gate close time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	1.0
<b>Supplementary loading signal</b>  SQ- 07 Times of "ON" of the supplementary loading				





Item	Function	Setting value		Default
		Parameter	Description	
SQ- 10	Discharge start delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is ON.	0.0
SQ- 11	Discharge stop delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is OFF.	0.0
SQ- 12	Discharge time	0.0 ~ 25.5 (sec)	Won't activate internal discharge control function, if set to 0.	0
<p>Discharge input signal</p> <p>Discharge output signal</p> <p>Weight reach zero band</p> <p>SQ- 10</p> <p>SQ- 11</p>				
SQ- 13	Restart delay time	0.0 ~ 25.5 (sec)	Delay time before Restart signal is ON.	1.0
SQ- 14	Batching counts	0 ~ 255 (times)	Number of batch runs 0 ⇒ one batch only	0
SQ- 15	Set the zero band in to final weighing value	0 1	No setting Setting	0
SQ- 16	Hi, OK, Lo	0	Comparison anytime	0
		1	To compare at batch finish	
		2	To compare at external input signal	
		3	To compare at batching finish and external input signal.	
		4	Comparison auto	
SQ- 17	Auto totalise weight / counts	0 1	Disabled Enabled	0
SQ- 18	The parameter source in weight comparison	0 1	Key in directly from front keypad Input directly from rear interface	0
SQ- 19	Weight comparison delay time	0.0 ~ 25.5 (sec)	Comparison delay time for Hi, OK, Lo	0.5
SQ- 20	TARE auto.	0 1	Press keypad TARE to TARE TARE auto	0
SQ- 21	Discharge auto	0 1	Input from external input or keypad Discharge auto + manual	0



## 4-2 Check weighing configuration

### 1. FNC-04 = 1, SQ-01 = 1,2,4 or 5



**2. FNC-04 = 1, SQ-01 = 3**

Press the Key →



Display shows the existing Hi value setting.  
Input new value as required.

Press



Display shows the existing Lo value setting.  
Input new value as required.


Press




Display shows the existing Zero Band setting.  
Input new value as required.

Press


	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

EXCELL®  
3. FNC-04 = 1, SQ-01 = 6


Display shows the existing **Hi value** setting,  
Input new value as required.




Display shows the existing **Lo value** setting.  
Input new value as required.



Display shows the existing **Zero Band**  
setting, Input new value as required.



Display show the existing **Peak Ready**  
**value** setting. Input new value as required.



<b>F1</b>	↑	⇒ Increment flashing digit
<b>F</b>	↓	⇒ Decrement flashing digit
<b>→0←</b>	ZERO	⇒ Move flashing point left.
<b>→T←</b>	TARE	⇒ Move flashing point right
<b>←</b>	ENTER	⇒ Store data in memory
<b>I/O</b>	ESC	⇒ Exit / Escape



## 4-3 Batching signal outputs

### 2 Normal batching signal outputs


Signal	Output condition
SP1	Net $\geq$ Final - SP1
SP2	Net $\geq$ Final - SP2
SP3	Net $\geq$ Final – Free Fall (in-flight)
Under	Net $<$ Final – Under
Over	Net $>$ Final + Over
Zero Band	Gross $\leq$ Zero Band

### 2 Loss-in-weight signal outputs

Signal	Output condition
SP1	Gross $\geq$ SP1
SP2	- Net $\geq$ Final – SP2
SP3	- Net $\geq$ Final – Free Fall (in-flight)
Under	- Net $<$ Final – Under
Over	- Net $>$ Final + Over
Zero Band	Gross $\leq$ Zero Band




## 4-4 Normal batching flow chart (SQ-01=1)






## 4-5 Loss-in Weight flow chart ( SQ1 = 2 )






## 4-6 Hi, OK, Lo output flow chart






## 4-7 Normal batching (built-in program) flow chart (SQ-01=4)






## 4-8 Loss-in Weight (built in program) (SQ-01=5)






## 4-9 Hold mode (SQ-01 = 6)

### 1. General hold mode (FNC-11 = 0)




### 2. Peak hold mode



Peak hold mode with four different states ( FNC-11 = 1,2,3,4 ), positive peak weight(1), negative peak weight, absolute value of peak weight(3) and positive peak weight(2) . The peak holds of absolute value and positive peak weight (2) both have no peak ready signal output.



## 4-9-1 Hold mode flow chart





## 4-9-2 Hi, OK, Lo comparison

### 1. Normal HOLD ( FNC-11 = 0 )

Entering the Hold mode, Hi, OK, Lo comparison output. Escape Hold mode will switch off the outputs.

### 2. Peak HOLD ( FNC-11 = 1, 2 )

If Peak Ready is ON, Hi, OK, Lo comparison output. Escape Hold mode will switch off the outputs.

### 3. The absolute value of peak HOLD ( FNC-11 = 3 )

Entering the Hold mode, Hi, OK, Lo will refer to Peak value to do the comparison.

## 4-10 Totalizing (ACCU.) Auto / Transmit

With automatic totalising active (SQ-17) or RS232 / RS485 or BCD output set to auto transmit.

### 1. SQ-01 = 1, 2, 4 or 5 batch / loss-in weight

- When the weight reaches the Final weight and the batch finish signal is ON the net weight will be added to the totaliser and number of additions is incremented. The RS232 / RS485 and BCD outputs transmit data.
- When the net weight returns to the zero range (FNC-10), then the sequence in a) above can be repeated.

### 2. SQ-01 = 3 Comparison mode

- When the net weight exceeds the zero range and the weight has stabilized it will be added to the totaliser and number of additions is incremented. The RS232 / RS485 and BCD outputs transmit data.




# CHAPTER 5 INTERFACE

## 5-1 Serial input/output interface (default OP-01)


### 2 Pin location and setting

#### 1. Default RS232 and Current-loop



PIN	Function
5	Current loop out
6	Current loop out
7	TXD
8	RXD
9	SG


#### 2. OP-01 RS422/RS485/RS232



PIN	Function	
	RS422/RS485	RS232
1	SDA	TXD
2	SDB	
3	RDA	RXD
4	RDB	
5	TRM	
6	SG	SG



### 2 Jumper configuration

#### 1. OP-01 RS422/RS485/RS232







## 2 Connection type

**RS-422****RS-485**



## 2 Function setting

First serial port interface 08 898  
Setting procedure



	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



Item	Function	Setting value		Default
		Parameter	Description	
RS1- 01 RS2- 01	Transmit format	0	As display	0
		1	Gross only	
		2	Net only	
		3	As display (simple)	
		4	Gross (simple)	
		5	Net (simple)	
		6	Comparison + As display (simple)	
		7	Comparison +Gross (simple)	
		8	Comparison +Net (simple)	
		9	Tare	
RS1- 02 RS2- 02	Transmit mode	10	Totalised (Accu.) Weight and number of transactions	
		0	Transmit continuous + command mode	0
		1	Auto transmit + command mode	
		2	Manual transmit + command mode	
RS1- 03 RS2- 03	Transmit speed	0	600	2
		1	1200	
		2	2400	
		3	4800	
		4	9600	
		5	19200	
RS1- 04 RS2- 04	Parity Bit length Stop Bit	0	N, 8, 1	2
		1	O, 7, 1	
		2	E, 7, 1	
RS1- 05 RS2- 05	Transmit times	0	Open	0
		1	1 time/sec.	
		2	2 time/sec.	
		3	5 time/sec.	
		4	10 time/sec.	
RS1- 06 RS2- 06	Transmission conditions	0 0 0 0 0 0	0 ⇒ transmit cont. 1 ⇒ Stop transmit	000000
		 Negative(Net Wt.) Weight unstable Overload (OL)		
RS1- 07 RS2- 07	Indicator polling address	00 ↓ 99	When set to 0, Indicator addressing is not used.	0



## 2 Data format

### 1. General Format

NET	S	T	,	G	S	,	+	0	1	2	3	4	5	6	k	g	CR	LF
GROSS	S	T	,	N	T	,	+	1	2	3	4	.	5	6		g		
TARE	S	T	,	T	R	,	+	0	1	2	3	4	5	6		t		
+ OL	O	L	,	G	S	,	+	SP										
- OL	O	L	,	G	S	,	-	SP										
UNSTABLE	U	S	,	G	S	,	+	1	2	3	4	.	5	6	k	g		

### 2. Totalised (Accu.) Format

Accu. Weight	T	W	,	+	1	2	3	4	5	6	.	7	8	9	k	g	CR	LF
Accu. Wt. Over+	T	W	,	+	SP													
Accu. Wt. Over -	T	W	,	-	SP													
Accu. Count	T	N	,	+	0	1	2	3	4	5	6	7	8	9	SP	SP		
Accu. Count over	T	N	,	+	SP													

### 3. Sample Format

Gross/Net or as display	+	1	2	3	4	5	6	CR	LF
Over load positive	+	SP	SP	SP	SP	SP	SP		
Over load negative	-	SP	SP	SP	SP	SP	SP		

### 4. Setpoint (1) + Simple Format (Gross/Net or as display)

	+	1	2	3	4	5	6	CR	LF
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0		

- bit 0 : Zero Band
- bit 1 : Over
- bit 2 : Under / Hi
- bit 3 : SP1 / Go
- bit 4 : SP2 / Lo
- bit 5 : SP3
- bit 6 : Discharge
- bit 7 : Batch finished



## 5. Comparison condition (2)

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
--------	--------	--------	--------	--------	--------	--------	--------

Byte 0 : Zero Band

Byte 1 : Over

ON : 0 ( ASCII Code 30 H )

Byte 2 : Under / Hi

OFF : 1 ( ASCII Code 31 H )

Byte 3 : SP1 / Go

Byte 4 : SP2 / Lo

Byte 5 : SP3

Byte 6 : Discharge

Byte 7 : Batch finished

## Description

	Output	ASCII	Description
Status 1	OL	4FH, 4CH	Over load
	ST	53H, 54H	Weight stable
	US	55H, 53H	Weight unstable
Status 2	GS	47H, 53H	Gross Weight
	NT	45H, 54H	Net Weight
	TR	54H, 52H	TARE
	TW	54H, 57H	Totalised Weight
	TN	54H, 4EH	Number of transactions in total
Data of Weight	0 ~ 9	30H ~ 39H	Figure of weight
	+, -	2BH, 2DH	Symbol (+ or -) of weight
	Space	20H	Over load
	.	2EH	Decimal
Units	Space, Space	20H, 20H	None
	kg	6BH, 67H	kg
	Space t	20H, 74H	tonne
	lb	6CH, 62H	lb
Ending code	CR, LF	0DH, 0AH	Ending code
Separating code	,	2CH	Comma



## 2 Command mode

### 1. Command Format A

Host	Command	<CR><LF>
Slave		Command <CR><LF>

MZ	Zero	CZ	Zero compensation On/OFF
MT	Tare	CT	Clear TARE value
MG	Gross Weight	MN	Net weight
AT	Accu. Current net weight and times plus 1.		
ST	Deduct times of last accu. Value minus 1		
DT	Clear accu. Value and times		
BB	Start batching (one time)	HB	Load stop
BC	Start batching (continuous)		
BD	Start unload		
SC	Transmit continuous	SA	Auto transmit
SM	Manual transmit	SO	Command mode
%	Stop continuous transmission and enter the command mode		

### 2. Command Format B

Host	Command	<CR><LF>
Slave		Data <CR><LF>

RW	Read current weight	RT	Read TARE
RG	Read Gross Weight	RN	Read Net weight
RB	Read current display of wt (simple)	RH	Read Gross (simple)
RI	Read Net (simple)		
RJ	Read comparison situation + current display of weight (simple)		
RK	Read comparison situation + Gross (simple)		
RL	Read comparison situation + Net (simple)		
RO	Read comparison situation (2)		
RF	Read prior completed weight	RA	Read accu. Value (incl. times)

**Note : Prior command plus %**

Read Weight Compared value: RS□□

FW	Read target item of unload value	S1	Read SP1
S2	Read SP2	S3	Read SP3
UD	Read Under	LO	Read LO
ZB	Read Zero Band	HI	Read HI
PR	Reading Peak value	OV	Read Over

**Ex:**

Command : RSFW < CR > < LF >

EX2002 reply : RSFW□□□□□□

Finish 6 bytes



### 3. COMMAND FORMAT C

Host	Command + Data<CR><LF>
Slave	Command + Data<CR><LF>

Write weight compared value                            WS□□XXXXXX  
    □□ : setting items  
    XXXXXX : value (6 bytes)

FW	Write target item of unload value	S1	Write SP1
S2	Write SP2	S3	Write SP3
UD	Write Under	LO	Write LO
ZB	Write Zero Band	HI	Write HI
PR	Write Peak value	OV	Write Over

## 2 Error messages

E1: Format command fault

E2: Setting parameters over range

E3: Command not recognised

## 2 Indicator polling address

If the indicator has an address configured in RS1(2) – 07, it will only respond to messages prefixed with its address.

For example: The indicator polling address is set to 02, it would send the weight value only if it received the command:-


@02RW < CR > < LF >



## 5-2 BCD parallel output interface (OP-02) 8 S 8 8 8


### 2 PIN Location

D-Sub 37PIN



PIN	Function	PIN	Function
1	SG	20	SG
2	$1 \times 10^0$	21	$2 \times 10^0$
3	$4 \times 10^0$	22	$8 \times 10^0$
4	$1 \times 10^1$	23	$2 \times 10^1$
5	$4 \times 10^1$	24	$8 \times 10^1$
6	$1 \times 10^2$	25	$2 \times 10^2$
7	$4 \times 10^2$	26	$8 \times 10^2$
8	$1 \times 10^3$	27	$2 \times 10^3$
9	$4 \times 10^3$	28	$8 \times 10^3$
10	$1 \times 10^4$	29	$2 \times 10^4$
11	$4 \times 10^4$	30	$8 \times 10^4$
12	$1 \times 10^5$	31	$2 \times 10^5$
13	$4 \times 10^5$	32	$8 \times 10^5$
14	Gross / - Net	33	Stable / - MD
15	Plus / - Minus	34	DP1
16	DP2	35	DP3
17	DP4	36	Over / - Normal
18	Data ready	37	Hold input
19			

### 2 Equivalent Circuit




Open Collector Output (OP-02-1)

TTL Output (OP-02-2)

Hold Input



## 2 Function setting




	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Item	Function	Setting value		Default
		Parameter	Description	
bCd- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
bCd- 02	Transmit mode	0	Transmit continuous	0
		1	Auto transmit	
		2	Manual transmit	
bCd- 03	Output Logic	0	Positive logic action	0
		1	Negative logic action	
bCd- 04	Data ready Signal logic	0	Positive logic action	0
		1	Negative logic action	
bCd- 05	OL output code	0	FFFFFF	0
		1	999999	
bCd- 06	Data code	0	BCD Code	0
		1	Hex. Code	



## 5-3 Analogue Current / Voltage Output Interface (OP-03)

### 2 Location



#### A. Terminal (4 way)

- 1 : 0 ~ 20mA current output, positive
- 2 : 0 ~ 10V voltage output, positive
- 3 : Current / voltage signal, negative
- 4 : Ground / 0V

#### B. SPAN adjustment

Current / voltage Span adjustment to increase value turn clockwise, decrease value turn anticlockwise.

#### C. ZERO adjustment


Current / voltage Zero adjustment to increase value turn clockwise, decrease value turn anticlockwise.

### 2 Analogue output interface specification

- Resolution : 16 bits
- Current output : 0 ~ 20mA ( 0 ~ 550 Ω load)
- Voltage output : 0 ~ 10V



## 2 Function setting



	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Item	Function	Setting value		Default
		Parameter	Description	
AnL- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
AnL- 02	Signal output	0	Current output	0
		1	Voltage output	
AnL- 03	Weight in Lo	000000 ~ 999999	When the weight reaches the value of that in AnL-03, the current / voltage output is changed to that configured in AnL-04.	0
AnL- 04	Current / Voltage in Lo	0.0 mA ~ 20.0 mA or 0.0 V ~ 10.0 V		
AnL- 05	Weight in Hi	000000 ~ 999999	When the weight reaches the value of that in AnL-05, the current / voltage output is changed to that configured in AnL-06.	300000
AnL- 06	Current / Voltage in Hi	0.0 mA ~ 20.0 mA or 0.0 V ~ 10.0 V		



## 2 Analogue output notes

1. The current output, load resistor should not exceed  $550\ \Omega$ . It is recommended that a resistor with a low temperature coefficient and a power rating above 0.2 W be used.
2. Avoid short circuits between the positive and negative analogue output terminals as the interface this may cause damage.
3. It is recommended that a screened cable is used to connect the analogue output to its load and that the screen is earthed to avoid noise interference.



## 5-4 External parallel input / output interface

### 2 PIN location


D-Sub 37PIN

20

37

1

19



### 2 OP-04 Control I/O (4 in / 4 out) + Setpoint Input (BCD code)


PIN	I/O	Signal	PIN	I/O	Signal
1	IN	Code $10^0$	20	IN	Code $10^1$
2	IN	Code $10^2$	21	IN	Code $10^3$
3	IN	Code $10^4$	22	IN	Code $10^5$
4	IN	Code $10^6$	23	IN	Code $10^7$
5	IN	Code $10^8$	24	IN	Code $10^9$
6	IN	Code $10^{10}$	25	IN	Code $10^{11}$
7			26		
8			27	OUT	OUT 0
9	OUT	OUT 1	28	OUT	OUT 2
10	OUT	OUT 3	29	IN	Vex
11		COM 2	30		COM 2
12			31		
13		COM 1	32		COM1
14	IN	IN 0	33	IN	IN 1
15	IN	IN 2	34	IN	IN 3
16			35		
17			36	IN	Code 1
18	IN	Code 2	37	IN	Code 4
19	IN	Code 8			

### 2 OP-05 Control I/O (8 in / 8 out)

PIN	I/O	Signal	PIN	I/O	Signal
1	IN	IN 0	20		COM 1
2	IN	IN 1	21		COM 1
3	IN	IN 2	22		COM 1
4	IN	IN 3	23		COM 1
5	IN	IN 4	24		COM 1
6	IN	IN 5	25		COM 1
7	IN	IN 6	26		COM 1
8	IN	IN 7	27		COM 1
9		COM 1	28		COM 1
10		COM 2	29		COM 2
11	OUT	OUT 0	30		COM 2
12	OUT	OUT 1	31		COM 2
13	OUT	OUT 2	32		COM 2
14	OUT	OUT 3	33		COM 2
15	OUT	OUT 4	34		COM 2
16	OUT	OUT 5	35		COM 2
17	OUT	OUT 6	36		COM 2
18	OUT	OUT 7	37		COM 2
19	IN	Vex			



## 2 Input signal configuration




	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Item	Function	Setting value			Default
		Parameter	P	Description	
IN - 01	Input 1	0	⇒ None		1
		1	⇒ Zero		
IN - 02	Input 2	2	⇒ Tare		2
		3	⇒ Tare reset		
IN - 03	Input 3	4	⇒ Start batching		3
		5	⇒ Stop batching		
IN - 04	Input 4	6	⇒ Discharge Command		4
		7	⇒ Hold		
IN - 05	Input 5	8	⇒ Hold display & I/O reset		5
		9	⇒ Totalise (Accu) Command		
IN - 06	Input 6	10	⇒ Clear totaliser (Accu)		6
		11	⇒ Clear previous total (Accu) Value.		
IN - 07	Input 7	12	⇒ Start to compare		7
		13	⇒ Serial and parallel printer manual output		
IN - 08	Input 8	14	⇒ Net / Gross		8



## 2 Output signal setting




	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Item	Function	Setting value		Default
		Parameter	Description	
OUT- 01	Output 1	0	⇒ None	1
		1	⇒ Zero band	
OUT- 02	Output 2	2	⇒ SP1	2
		3	⇒ SP2	
OUT- 03	Output 3	4	⇒ SP3	3
		5	⇒ Batching completed	
OUT- 04	Output 4	6	⇒ Discharge	4
		7	⇒ Peak ready	
OUT- 05	Output 5	8	⇒ Stable	5
		9	⇒ Internal batching process running	
OUT- 06	Output 6	10	⇒ Under	6
		11	⇒ Over	
OUT- 07	Output 7	12	⇒ Hi	7
		13	⇒ OK	
OUT- 08	Output 8	14	⇒ Lo	8
OUT-09	The output logic of OUT-04~OUT-01	0000 à positive logic 1111 à negative logic		0000
OUT-10	The output logic of OUT-08~OUT-05	0000 à positive logic 1111 à negative logic		0000




## 2 Equivalent Circuits



**4** IN 1 ~ IN 8 and COM 1. Input signal - Open  $\leftrightarrow$  OFF, Short  $\leftrightarrow$  ON.

**4** Warning: Don't use external power (AC or DC) to connect to the input terminals.

### Output





## 2 Thumbwheel Switches (for OP-04)

The interface can connect to external thumbwheel switches or a PLC to input various parameters depending on the configuration of SQ-01. The input variables are:-

- Final (5 digits), SP2 (4 digits) & Free Fall (3 digits)


or

- , Hi (6 digits), Lo (6 digits)


When using external thumbwheel Switches, SQ-18 should be set to 1.

### Connection data

SQ-01 = 1, 2, 4 or 5



SQ-01 = 3 or 6





## CHAPTER 6 MAINTENANCE

### 6-1 Restore all parameters to their default factory values.

(1) While the indicator is counting back to zero, adjust SW to ON and press

(2) Display shows the flashing digits

(3) Confirm / abort


(3-1) To confirm press key & don't release it until the display shows

, then release the key and return the calibration SW to OFF.

(3-2) To abort, set the calibration SW to OFF directly.

### 6-2 Maintenance function parameters

Power on the machine. Press keys while the display counts back to zero.





## 6-2-1 Restore the function parameter back to its default value.

(1) During the indicator count back to zero, press

(2) The display shows

(3) Press key and the display shows flashing.

(4) Confirm / abort

(4-1) To confirm, press the key & don't release it. The display will then show

(4-2) To abort press the key or switch the power off.

## 6-2-2 Clear zero compensation and TARE values

(1) During the indicator count back to zero, press

(2) The display shows press the F1 key to display

(3) Press key, the display shows flashing.

(4) Confirm / abort

(4-1) To confirm press the key & don't release it. The display will then show

(4-2) To abort press the key or switch the power off.

## 6-2-3 Clear batch setting

(1) During the indicator count back to zero, press

(2) The display shows press the F1 key to display

(3) Press key, the display shows flashing.

(4) Confirm / abort

(4-1) To confirm press the key & don't release it. The display will then show

(4-2) To abort press the key or switch the power off.

## 6-2-4 Display zero voltage (mV/V)

(1) During the indicator count back to zero, press

(2) The display shows press the F1 key to display

(3) Press key the display shows the zero voltage (mV/V). e.g.

(4) Press key or switch the power off.



## 6-2-5 Clear batch setting

(1) During the indicator count back to zero, press

(2) The display shows press the F1 key to display


(3) Press the key, the display shows the span voltage (mV/V).  
e.g.

(4) Press key or switch the power off.



## 6-3 Test mode

During the indicator count back to zero





### 6-3-1 7 segment display testing

The display will show ~ , then display “.” and all of the icons. To exit press

### 6-3-2 Keypad and calibration SW testing

Setting the calibration SW to “ON”, or pressing any key will cause the related display segment to change from → . To exit press

### 6-3-3 Display A/D internal value display

Display range is 0 ~ 520,000d (-0.1mV/V ~ 4.0mV/V). To exit press

### 6-3-4 RS-232 serial loop back testing

Terminal pin 7 and pin 8 must be connected together at the rear of the indicator.

If display shows , the interface is working normally. If display shows , the interface is not working correctly.

### 6-3-5 EEPROM memory testing

If the display shows , it means normal. If the display shows , the memory is not working correctly.



### 6-3-6 Option interface card testing

#### 2 OP-01 RS232/RS422/RS485 testing

##### 1) RS232 testing

J1~J4 ⇒ 1, 2 short (Adjust J1~J4 mini jumper to 2, 3)

Terminal pin 1 and pin 3 must be connected together at the rear of the indicator.

If display shows , the interface is working normally. If display shows , the interface is not working correctly.

##### 2) RS422 testing

J1~J4 ⇒ 1, 2 short (Adjust J1~J4 mini jumper to 1, 2)

J5~J6 ⇒ 1, 2 short (Adjust J5~J6 mini jumper to 1, 2)

Terminal pin1 and pin 3, pin 2 and pin 4 must be separately connected together at the rear of the indicator.

If display shows , the interface is working normally. If display shows , the interface is not working correctly.

#### 2 OP-02 BCD parallel output interface testing

1) A flashing decimal point indicates the test procedure is active.

2) Program will transmit OFF → ON → OFF signal for each output bit of the BCD interface in sequence.



## 2 OP-03 Analogue current output interface testing

### 1) 4 ~ 20mA current output testing

Use an ammeter to measure the output current between pin1 & pin 3 of the interface.

Use the keys to select the output current level desired.

⇒ 4mA  
 ⇒ 12mA  
 ⇒ 20mA

### 2) 0 ~ 10V voltage output testing

Use a voltmeter to measure the voltage between pin 2 & pin 3 of the interface.

Use the keys to select the output voltage level desired.

⇒ 1V  
 ⇒ 5V  
 ⇒ 10V

**4 Warning: To avoid damage to components use only a voltmeter.**

## 2 OP-04 Control I/O (4I/4O) testing

1)


Input1 ~ 4 output signal ON/OFF, related to display →

Press Key  
 ~ in sequence, represents Outputs 1 ~ 4

2) Press key to switch to the control input value.



## 2 OP-05 Control I/O (8I/8O) testing





## APPENDIX I Description of 7 segment characters

Digit	7 segments letter	Alphabet	7 segments letter	Alphabet	7 segments letter
0		A		N	
1		B		O	
2		C		P	
3		D		Q	
4		E		R	
5		F		S	
6		G		T	
7		H		U	
8		I		V	
9		J		W	
		K		X	
		L		Y	
		M		Z	



## APPENDIX II Function Table

### Specification Calibration

Item	Function	Setting Value		Default
		Parameter	Description	
CSP-01	Unit	0	None	2
		1	g	
		2	Kg	
		3	t	
		4	lb	
CSP-02	Decimal Point	0	None	0
		1	1 Decimal Point	
		2	2 Decimal Point	
		3	3 Decimal Point	
CSP-03	Division	1	Division	1
		2		
		5		
		10		
		20		
		50		
CSP-04	Max. Capacity	999999 ↓ 000000	Max. capacity	999999
CSP-05	Zero range	0 =full range (±1%~30%)	Zero range = calibration zero point ± (Max. capacity×setting value %)	0
CSP-06	Time of zero tracking	0.0 ~ 5.0 (sec)	Time and range of zero tracking should be use at the same time. If the time is set to 0.0, the zero tracking function is disabled.	1.0
CSP-07	Range of zero tracking	0 ~ 9	Range of zero tracking = (setting value×½)D , D=min. division Range and time of zero tracking should be use at the same time. If the range is set to 0, the zero tracking function is disabled.	2
CSP-08	Investigate time in stable	0.0 ~ 5.0 (sec)	Investigate time and range should be use at the same time. If the time is set to 0.0, the investigate time is disabled.	1.0
CSP-09	Investigate range in stable	0 ~ 9	Investigate time and range should be use at the same time. If the range is set to 0, the investigate range is disabled.	2
CSP-10	Weight unstable, function ZERO and TARE	0	Action	0
		1	None	
CSP-11	Gross Weight is negative, function TARE	0	Action	0
		1	None	



## 2 FNC GROUP FUNCTION SETTING

Item	Function	Setting value			Default	
		Parameter	Description			
FNC-01	Digital Filter I	0	5 Hz		4	
		1	4.17 Hz			
		2	2.5 Hz			
		3	2.08 Hz			
		4	1.25 Hz			
		5	1.04 Hz			
		6	0.63 Hz			
		7	0.52 Hz			
		8	0.31 Hz			
		9	0.26 Hz			
FNC-02	Digital Filter II	0	Disabled		2	
		1	Less filter			
		2				
		3				
		4				
		5	Greater			
FNC-03	Key – Locked	000000 ↓ 111111	0 1	Normal (lock disable) Close (lock enable)	The bits and front panel key positions are related to each other. 000000	
FNC-04	“F” function setting	Parameter ⇒ Description 2 ⇒ Display Net / Gross weight 3 ⇒ Setpoint parameter setting 2 ⇒ Tare reset 3 ⇒ Manual serial, parallel print output. 4 ⇒ Start load 5 ⇒ Stop load 6 ⇒ Start comparison 7 ⇒ Unload command 8 ⇒ Totalise weight and counts command 9 ⇒ Clear totalised weight and counts 10 ⇒ Hold mode 11 ⇒ Escape Hold mode (I/O DSP) 12 ⇒ Convert to Gross / Net / totalised weight / totalised Count				
FNC-05	“F1” function setting					



Item	Function	Setting value		Default
		Parameter	Description	
FNC-06	Front panel indication “◀” setting (top)	Parameter ⇒ Description		
		0	⇒ Zero	0
		1	⇒ MD	
		2	⇒ Gross	
		3	⇒ Net	
		4	⇒ Totalised weight (Accu. V)	
FNC-07	Front panel indication “◀” setting (next to top)	5	⇒ Totalised transactions (Accu. C)	1
		6	⇒ SP1	
		7	⇒ SP2	
		8	⇒ SP3	
FNC-08	Front panel indication “◀” setting (next to bottom)	9	⇒ Hi	2
		10	⇒ OK	
		11	⇒ Lo	
		12	⇒ Under	
FNC-09	Front panel indication “◀” setting (bottom)	13	⇒ Over	
		14	⇒ Discharge	3
		15	⇒ Running	
		16	⇒ Hold	
FNC-10	Return to zero band	0	5 d	0
		1	10 d	
		2	20 d	
		3	40 d	
		4	60 d	
		5	80 d	
		6	100 d	
		7	150 d	
		8	200 d	
		9	250 d	
FNC-11	Hold	0	Hold	0
		1	Peak hold (positive)	
		2	Peak hold (negative)	
		3	Peak hold (absolute value)	
FNC-12	Rate for display rewrite	0	No limitation	0
		1	20 times/sec	
		2	10 times/sec	
		3	5 times/sec	
		4	1 time/sec	

**Serial Input/Output Interface (Build in OP-1)**

Item	Function	Setting value		Default
		Parameter	Description	
RS1- 01 RS2- 01	Transmit format	0	As display	0
		1	Gross only	
		2	Net only	
		3	As display (simple)	
		4	Gross (simple)	
		5	Net (simple)	
		6	Comparison + As display (simple)	
		7	Comparison +Gross (simple)	
		8	Comparison +Net (simple)	
		9	Tare	
RS1- 02 RS2- 02	Transmit mode	10	Totalised (Accu.) Weight and number of transactions	
		0	Transmit continuous + command mode	0
		1	Auto transmit + command mode	
		2	Manual transmit + command mode	
RS1- 03 RS2- 03	Transmit speed	3	Command mode	
		0	600	2
		1	1200	
		2	2400	
		3	4800	
		4	9600	
RS1- 04 RS2- 04	Parity Bit length Stop Bit	5	19200	2
		0	N, 8, 1	
		1	O, 7, 1	
RS1- 05 RS2- 05	Transmit times	2	Even parity, 7 data bits, 1 Stop bit	
		0	Open	0
		1	1 time/sec.	
		2	2 times/sec.	
		3	5 times/sec.	
RS1- 06 RS2- 06	Transmission conditions	4	10 times/sec.	
		0 0 0 0 0	0 ⇒ transmit cont. 1 ⇒ Stop transmit	000000
			Negative(Net Wt.) Weight unstable Overload (OL)	
RS1- 07 RS2- 07	Indicator poling address	00 ↓ 99	When set to 0, Indicator addressing is not used.	0



## BCD Parallel Output Interface (OP – 02)

Item	Function	Setting value		Default
		Parameter	Description	
bCd- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
bCd- 02	Transmit mode	0	Transmit continuous	0
		1	Auto transmit	
		2	Manual transmit	
bCd- 03	Output Logic	0	Positive logic action	0
		1	Negative logic action	
bCd- 04	Data ready Signal logic	0	Positive logic action	0
		1	Negative logic action	
bCd- 05	OL output code	0	FFFFFF	0
		1	999999	
bCd- 06	Data code	0	BCD Code	0
		1	Hex. Code	



## Analogue Current/Voltage Output Interface (Op - 03)

Item	Function	Setting value		Default
		Parameter	Description	
AnL- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
AnL- 02	Signal output	0	Current output	0
		1	Voltage output	
AnL- 03	Weight in Lo	000000 ~ 999999	When the weight reaches the value of that in AnL-03, the current / voltage output is changed to that configured in AnL-04.	0
AnL- 04	Current / Voltage in Lo	0.0 mA ~ 20.0 mA or 0.0 V ~ 10.0 V		
AnL- 05	Weight in Hi	000000 ~ 999999	When the weight reaches the value of that in AnL-05, the current / voltage output is changed to that configured in AnL-06.	300000
AnL- 06	Current / Voltage in Hi	0.0 mA ~ 20.0 mA or 0.0 V ~ 10.0 V		




## External Parallel Input/Output Interface (Op-04 & Op-05)

Item	Function	Setting value		Default
		Parameter	⇒ Description	
IN - 01	Input 1	0	⇒ None	1
		1	⇒ Zero	
IN - 02	Input 2	2	⇒ Tare	2
		3	⇒ Tare reset	
IN - 03	Input 3	4	⇒ Start batching	3
		5	⇒ Stop batching	
IN - 04	Input 4	6	⇒ Discharge Command	4
		7	⇒ Hold	
IN - 05	Input 5	8	⇒ Hold display & I/O reset	5
		9	⇒ Totalise (Accu) Command	
IN - 06	Input 6	10	⇒ Clear totaliser (Accu)	6
		11	⇒ Clear previous total (Accu) Value.	
IN - 07	Input 7	12	⇒ Start to compare	7
		13	⇒ Serial and parallel printer manual output	
IN - 08	Input 8	14	⇒ Net / Gross	8


Item	Function	Setting value		Default
		Parameter	Description	
OUT- 01	Output 1	0	⇒ None	1
		1	⇒ Zero band	
OUT- 02	Output 2	2	⇒ SP1	2
		3	⇒ SP2	
OUT- 03	Output 3	4	⇒ SP3	3
		5	⇒ Batching completed	
OUT- 04	Output 4	6	⇒ Discharge	4
		7	⇒ Peak ready	
OUT- 05	Output 5	8	⇒ Stable	5
		9	⇒ Internal batching process running	
OUT- 06	Output 6	10	⇒ Under	6
		11	⇒ Over	
OUT- 07	Output 7	12	⇒ Hi	7
		13	⇒ OK	
OUT- 08	Output 8	14	⇒ Lo	8
OUT- 09	The output logics of OUT-04~OUT-01	0000 à positive logic 1111 à negative logic		0000
OUT- 10	The output logics of OUT-08~OUT-05	0000 à positive logic 1111 à negative logic		0000



Item	Function	Setting value		Default
		Parameter	Description	
SQ- 01	Batching mode	1	Normal batch	1
		2	Loss-in weight	
		3	Comparison mode	
		4	Normal batch (Built-in program)	
		5	Loss-in weight (Built-in program)	
		6	Hold mode (Built-in program)	
SQ- 02	Batching start delay time	0.0 ~ 25.5 (sec)	The built-in auto-program starts the batch comparison procedure after the input of the batch start signal.	0.0
SQ- 03	SP1,SP2 Waiting time comparison	0.0 ~ 25.5 (sec)	No full flow comparison during this function's set time period. If the set value is 0, indicates this function is not in use.	0.0
SQ- 04	Batch finish output signal delay time	0.0 ~ 25.5 (sec)	Output the batch finished signal after this delay time.	0.5
SQ- 05	Batch finish Condition	0 1	Wait until the weight is stabilized No need to wait until the weight has stabilized	0
SQ- 06	Batch finish Output signal time	0.0 ~ 25.5 (sec)	Batch finished output signal time. If set to 0, the output signal will be off until the next batch start.	1.0



SQ- 07	Number of Times the supplementary loading function operates	0 ~ 255	If the set value is 0, this function is not in use.	0
SQ- 08	Supplementary loading gate open time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	0.1
SQ- 09	Supplementary loading gate close time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	1.0





## Function Configuration Menu

Item	Function	Setting value		Default
		Parameter	Description	
SQ- 10	Discharge start delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is ON.	0.0
SQ- 11	Discharge stop delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is OFF.	0.0
SQ- 12	Discharge time	0.0 ~ 25.5 (sec)	Won't activate internal discharge control function, if set to 0.	0
<p>The diagram illustrates the logic flow for a discharge operation. It starts with a 'Discharge input signal' (a pulse). This triggers 'SQ-10', which is a timer. When 'SQ-10' times out, it activates the 'Discharge output signal'. After a delay defined by 'SQ-11', the 'Discharge output signal' deactivates. A 'Weight reach zero band' is indicated during the active period of the discharge output.</p>				
SQ- 13	Restart delay time	0.0 ~ 25.5 (sec)	Delay time before Restart signal is ON.	1.0
SQ- 14	Batching counts	0 ~ 255 (times)	Number of batch runs 0 ⇒ one batch only	0
SQ- 15	Set the zero band in to final weighing value	0 1	No setting Setting	0
SQ- 16	Hi, OK, Lo	0	Comparison anytime	0
		1	To compare at batch finish	
		2	To compare at external input signal	
		3	To compare at batching finish and external input signal.	
		4	Comparison auto	
SQ- 17	Auto accu. weight / counts	0	Disabled	0
		1	Enabled	
SQ- 18	The parameter source in weight comparison	0	Key in directly from front keypad	0
		1	Input directly from rear interface	
SQ- 19	Weight comparison delay time	0.0 ~ 25.5 (sec)	Comparison delay time for Hi, OK, Lo	0.5
SQ- 20	TARE auto.	0	Press keypad TARE to TARE	0
		1	TARE auto	
SQ- 21	Discharge auto	0	Input from external input or keypad	0
		1	Discharge auto + manual	