



EXCELL® PRECISION CO. LTD.

# EX2005



# OPERATION MANUAL

© Excell Precision Limited 2005. All rights reserved Worldwide.

The information contained herein is the property of Excell Precision Limited and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorised by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.





EXCELL®

EXCELL PRECISION CO. LTD.

222

# TABLE OF CONTENTS

222

SAFETY .....	3
FEATURES .....	4
CHAPTER 1 FRONT AND REAR PANEL SPECIFICATIONS .....	5
1-1 Front Panel .....	5
1-2 Rear Panel .....	6
1-3 Keyboard Description .....	7
1-4 A/D Conversion .....	7
1-5 Power Supply .....	7
1-6 Dimensions .....	8
CHAPTER 2 GENERAL FUNCTION GUIDE .....	9
2-1 Function Setup and Operation Procedures .....	9
2-2 Function Setting .....	12
CHAPTER 3 CALIBRATION .....	15
3-1 Load Cell Connection .....	15
3-2 Parameter Setting and Calibration Flow Chart .....	16
3-3 MODBUS Calibration .....	18
3-4 Specification Calibration .....	19
3-5 General Calibration .....	21
3-6 Linearity Calibration .....	22
3-7 Digital Calibration .....	24
3-8 Calibration Error Messages .....	25
CHAPTER 4 WEIGHT COMPARISON PROCEDURES .....	26
4-1 Function Configuration Menu .....	26
4-2 Check Weighing Configuration .....	29
4-3 Batching Signal Outputs .....	32
4-4 Normal Batching Flow Chart (SQ-01=1) .....	33
4-5 Loss-in Weight Flow Chart ( SQ1 = 2 ) .....	34
4-6 Hi, OK, Lo Output Flow Chart .....	35
4-7 Normal Batching (Built-in Program) Flow Chart (SQ-01=4) .....	36
4-8 Loss-in Weight (Built in Program) (SQ-01=5) .....	37
4-9 Hold Mode (SQ-01 = 6) .....	38
4-9-1 Hold Mode Flow Chart .....	39
4-9-2 Hi, OK, Lo Comparison .....	40
4-10 Totalizing (ACCU.) Auto / Transmit .....	40
CHAPTER 5 INTERFACE .....	41
5-1 Serial Input/Output Interface (Built-in) .....	41
5-2 BCD Parallel Output Interface (OP-02) .....	49



---


5-3 Analogue Current Output Interface (OP-03) .....	51
5-4 External Parallel Input /Output Interface.....	54
 CHAPTER 6 MAINTENANCE .....	59
6-1 Restore all Parameters to The Default Factory Values. ....	59
6-2 Maintenance Function Parameters.....	59
6-2-1 Restore the Function Parameter Back to Its Default Value.....	60
6-2-2 Clear Zero Compensation and Tare Values.....	60
6-2-3 Clear Batch Setting .....	60
6-2-4 Display Zero Voltage (mV/V).....	60
6-2-5 Clear Batch Setting .....	61
6-3 Test Mode .....	62
6-3-1 7 Segment Display Testing.....	63
6-3-2 Keypad and Calibration SW Testing .....	63
6-3-3 Display A/D Internal Value Display .....	63
6-3-4 RS-232 Serial Loop Back Testing.....	63
6-3-5 EEPROM Memory Testing .....	63
6-3-6 Option Interface Card Testing .....	63
 APPENDIX I DESCRIPTION OF 7 SEGMENT CHARACTERS .....	65
APPENDIX II FUNCTION TABLE .....	66
APPENDIX III MODBUS DATA ADDRESS TABLE 1 .....	75
APPENDIX VI MODBUS DATA ADDRESS TABLE 2.....	76



EXCELL®

EXCELL PRECISION CO. LTD.

## SAFETY

- 
- A large gray warning triangle is positioned in the center of the page. Inside the triangle is a white exclamation mark symbol. The text below the triangle lists several safety instructions.
- 2 When the instrument is installed, connect an earth bonding conductor from FG to the earth connection marked “  $\pm$  ”.
  - 2 Disconnect the mains power supply before opening the instrument housing. NOTE: There are no user serviceable parts inside.
  - 2 To install the optional interface cards, it is necessary to disconnect the mains power supply and fit a yellow/green earth bonding cable to the rear panel.
  - 2 Before turning the power on ensure the supply voltage is within the acceptable range, DC12V~DC24V.
  - 2 The operating ambient temperature range is -10°C ~ +40°C.  
(+14°F ~ +104°F)



# FEATURES

EX2005 has a wide range of applications from batching to simple weighing.

## Features:

Stand alone batching mode or connect to PLC for external system control

Built in batching / dosing functions

Manual / automatic discharge operation

Set cycle times in a batch

Totalise weight and number of cycles

Key in the signal voltage value (mV/V) directly via the keyboard, no need to apply any weight to calibrate the system.

Display load cell output voltage (mV/V) for future maintenance

Adjustable filter

Built-in RS232C bi-directional interface or RS485 one way serial interface

Built-in MODBUS (RTU) format

## Interface options:

- |         |   |
|---------|---|
| OP-02-1 | BCD parallel output interface (Open collector output) |
| OP-02-2 | BCD parallel output interface (TTL output)            |
| OP-03   | 16 Bit Analogue current output interface (0 ~ 20 mA)  |
| OP-04   | Control I/O (4 In / 4 Out) + Setpoint In (BCD code)   |
| OP-04E  | Relay Output (4 In / 4 Out)                           |
| OP-04C  | Hi, Lo, OK input interface (BCD code)                 |
| OP-04F  | Setpoint input interface (BCD code)                   |
| OP-05   | Control I/O (8 In / 8 Out)                            |
| OP-05E  | Relay Output (8 In / 8 Out)                           |




EXCELL®

EXCELL PRECISION CO. LTD.

# CHAPTER 1 FRONT AND REAR PANEL SPECIFICATIONS

## 1-1 Front Panel



### Display

- 6 digits, bright red, 7 segment LED display, character height 16mm (0.63").  
Display can be switched between Gross Weight / Net Weight / Totalised Weight / Number of transactions in the total.

- Indication icons “◀”


ZERO	◀	: Zero Indication
MD	◀	: Unstable weight Indication
GROSS	◀	: Gross weight Indication
NET	◀	: Net weight Indication

- ◆ The indicator is supplied with suitable labels to customise the icon displays. Refer to FNC. 06 ~ FNC.09 for the various options available.

## 2 Weighing Units

- ◆ Weighing Units kg / g / t / lb.

## 1-2 Rear Panel



2 Calibration Switch set to the left is "OFF" and to the right is "ON"

2 13 Way Terminal Block

- |                  |                   |
|------------------|-------------------|
| 1 <sup>st</sup>  | : EARTH or GROUND |
| 2 <sup>nd</sup>  | : DC+             |
| 3 <sup>rd</sup>  | : DC-             |
| 4 <sup>th</sup>  | : Not Used        |
| 5 <sup>th</sup>  | : TXD / DA -      |
| 6 <sup>th</sup>  | : RXD / DA +      |
| 7 <sup>th</sup>  | : SG              |
| 8 <sup>th</sup>  | : EXC +           |
| 9 <sup>th</sup>  | : SEN +           |
| 10 <sup>th</sup> | : SEN -           |
| 11 <sup>th</sup> | : EXCITATION -    |
| 12 <sup>th</sup> | : SIGNAL +        |
| 13 <sup>th</sup> | : SIGNAL -        |



EXCELL®

EXCELL PRECISION CO. LTD.


## 1-3 Keyboard Description




- When entering data or reference setting, it means "ESC".  
In the normal operation, it puts the indicator in standby mode or escape.  
: Entering standby mode: All of the display (except ZERO "3" symbol) and serial data output are disabled.  
Escape from standby mode: Re-power on mains for normal operation.



- : When parameter setting, it moves the flashing digit left.  
: In the normal mode, it performs a Zero operation.




- : When parameter setting, it moves the flashing digit right.  
: In the normal mode, it performs a semi-auto Tare operation.



- When parameter setting, it increments the flashing digit or steps up the  
: select item.  
In the normal mode, it accesses the FNC-05 setting.



- When parameter setting, it decrements the flashing digit or steps down  
the select item.  
In the normal mode, it accesses the FNC-04 setting.



- : Confirm / enter key

- 4 Function FNC-03 can be used to selectively disable individual keys.
- 4 Zero operation, will be limited by functions CSP-05 and CSP-10.
- 4 Zero operation, will be limited by functions CSP-10 and CSP-11.

## 1-4 A/D Conversion





* Input Sensitivity	: Over 0.12µV/D
* Internal Resolution	: 1 / 1,000,000
* Max. Sampling Speed	: 120 times/sec.
* Application Range	: - 0.1 mV/V ~ 4.0 mV/V
* Load Cell Excitation Voltage	: 5 VDC ±5%, 120mA (Up to eight (8) 350 Ω load cells can be connected)

## 1-5 Power Supply

- ◆ DC12V ~ DC24V



## 1-6 Dimensions

**Panel Cutout**



EXCELL®

EXCELL PRECISION CO. LTD.

## CHAPTER 2 GENERAL FUNCTION GUIDE

### 2-1 Function Setup and Operation Procedures

Function	Operation	Display	Description
Enter calibration mode	Turn the calibration switch to “ON”	88 888	See 3-2 for details
Enter function setting	Press  not release, then press  key after the power is turned on	88 888	See 2-2 for details
Reset all parameters back to default	Turn the power on then turn the calibration switch to “ON” then press and hold the  and  keys during the self-testing sequence	8.888	See 6-1 for details
Reset general function parameters back to default	Turn the power on and press  and  keys during self-testing sequence	8 888	See 6-2-1 for details
Clear zero point compensation and tare value	Turn the power on and press  and  keys during self-testing sequence, and then press	2 8888	See 6-2-2 for details
Clear setpoint parameter setting	Turn the power on and press  and  keys during self-testing sequence, and then press  two times	3 888	See 6-2-3 for details
Value of zero point voltage(mV/V)	Turn the power on and Press  and  ,then press  three times.	8 8888	See 6-2-4 for details
Value of Span voltage (mV/V)	Turn the power on and Press  and  , then Press	5 8888	See 6-2-5 for details
Entering to test mode	Turn the power on and press  and  keys during self-testing sequence	8 888	See 6-3 for details



EXCELL®

EXCELL PRECISION CO. LTD.


Function	Operation	Display	Description
Check weighing setpoint parameter setting	Press the  key to set the parameter of FUNC.4 to 1 in the normal mode	 or 	See 4-2 for details

## 4 Key actions in function set up mode

- ⇒ Increases the number of the flashing digit
- ⇒ Decreases the number of the flashing digit
- ⇒ Moves the flashing digit one space to the left
- ⇒ Moves the flashing digit one space to the right
- ⇒ Saves the configuration
- ⇒ Quits set up mode / Escape



## 4 Function Setting Procedures






EXCELL®

EXCELL PRECISION CO. LTD.

## 2-2 Function Setting



To continue the next function setting

or press to escape

\*Function Parameter code

- |       |   |
|-------|---|
| 88888 | ⇒ Digital Filter I                            |
| 88882 | ⇒ Digital Filter II                           |
| 88883 | ⇒ Lock keypad function                        |
| 88884 | ⇒ "F" function setting                        |
| 88885 | ⇒ "F1" function setting                       |
| 88886 | ⇒ Front panel indication "◀" setting (first)  |
| 88887 | ⇒ Front panel indication "◀" setting (second) |
| 88888 | ⇒ Front panel indication "◀" setting (third)  |
| 88889 | ⇒ Front panel indication "◀" setting (fourth) |
| 88880 | ⇒ Terms of back to zero                       |
| 88881 | ⇒ Hold  |
| 88882 | ⇒ Rate for display rewrite                    |

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



EXCELL®

EXCELL PRECISION CO. LTD.

## 2 FNC Group Function Setting

Item	Function	Setting value			Default
		Parameter	Description		
FNC-01	Digital Filter I	0	5 Hz		4
		1	4.17 Hz		
		2	2.5 Hz		
		3	2.08 Hz		
		4	1.25 Hz		
		5	1.04 Hz		
		6	0.63 Hz		
		7	0.52 Hz		
		8	0.31 Hz		
		9	0.26 Hz		
FNC-02	Digital Filter II	0	Disabled		2
		1			
		2	Less filter		
		3			
		4			
		5	Greater		
FNC-03	Key – Locked	000000 ↓ 111111	0 1	Normal (lock disable) Close (lock enable)	The bits and front panel key positions are related to each other.  000000
FNC-04	“F” function setting	Parameter ⇒ Description 0 ⇒ Display Net / Gross weight 1 ⇒ Setpoint parameter setting 2 ⇒ Tare reset 3 ⇒ Manual serial, parallel print output. 4 ⇒ Start load 5 ⇒ Stop load 6 ⇒ Start comparison 7 ⇒ Unload command 8 ⇒ Totalise weight and counts command 9 ⇒ Clear totalised weight and counts 10 ⇒ Hold mode 11 ⇒ Escape Hold mode(I/O DSP) 12 ⇒ Convert to Gross / Net / totalised weight / totalised Count			
FNC-05	“F1” function setting				



EXCELL®


EXCELL PRECISION CO. LTD.

Item	Function	Setting value		Default
		Parameter	Description	
FNC-06	Front panel indication “◀” setting (top)	Parameter ⇒ Description 0 ⇒ Zero 1 ⇒ MD 2 ⇒ Gross 3 ⇒ Net 4 ⇒ Totalised weight (Accu. V) 5 ⇒ Totalised transactions (Accu. C) 6 ⇒ SP1 7 ⇒ SP2 8 ⇒ SP3 9 ⇒ Hi 10 ⇒ OK 11 ⇒ Lo 12 ⇒ Under 13 ⇒ Over 14 ⇒ Discharge 15 ⇒ Running 16 ⇒ Hold		0
FNC-07	Front panel indication “◀” setting (next to top)			1
FNC-08	Front panel indication “◀” setting (next to bottom)			2
FNC-09	Front panel indication “◀” setting (bottom)			3
FNC-10	Return to zero band	0 1 2 3 4 5 6 7 8 9	5 d 10 d 20 d 40 d 60 d 80 d 100 d 150 d 200 d 250 d	0
FNC-11	Hold	0 1 2 3 4	Hold Peak hold (positive 1) Peak hold (negative) Peak hold (absolute value) Peak hold (positive 2)	0
FNC-12	Rate for display rewrite	0 1 2 3 4	No limitation 20 times/sec 10 times/sec 5 times/sec 1 time/sec	0


# CHAPTER 3 CALIBRATION

## 3-1 Load Cell Connection


- 2 When using a 6 wire cable to connect the load cell, the SEN+ and SEN- can be left unconnected (see below diagram)



## 3-2 Parameter Setting and Calibration Flow Chart



## 2 Calibration process




4 Before the Linearity Calibration, the General Calibration should be completed.

### 3-3 MODBUS Calibration

2 RS1-02 set as “4” (MODBUS RTU mode)

RS1-07 set as “01” (address)



eg:

#### Zero calibration

Input 01050423FF007CC0 ← zero calibration

Reading calibration status

Input 0101004100565AC1D ← Refer to “Appendix 3: MODBUS data address table”

The zero calibration is finished, and there should be no Err message appeared.

#### Span calibration

Input weight calibration value 3000

Input 0110044C0001020BB8EADE ← Input weight calibration value 3000

Put 3kg on the platter

Span calibration

Input 01050424FF00CD01 ← Span calibration


Reading calibration status

Input 0101004100565AC1D ← Refer to “Appendix 3: MODBUS data address table”

The span calibration is finished, and there should be no Err message appeared.



### 3-4 Specification Calibration



or press to escape

\*Calibration parameter code

898808 ⇒ Unit

898802 ⇒ Decimal Point

898803 ⇒ Min. Division

898804 ⇒ Max. Capacity

898805 ⇒ Zero Range

898806 ⇒ Time of Zero tracking

898807 ⇒ Range of Zero tracking

898808 ⇒ Investigate period of unstable

898809 ⇒ Investigate range of unstable

898810 ⇒ Function Zero and Tare when the weight is unstable.

898811 ⇒ Tare function availability when gross weight is negative.

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



EXCELL®

EXCELL PRECISION CO. LTD.

Item	Function	Setting value		Default
		Parameter	Description	
CSP-01	Unit	0	None	2
		1	g	
		2	Kg	
		3	t	
		4	lb	
CSP-02	Decimal Point	0	None	0
		1	1 Decimal Point	
		2	2 Decimal Point	
		3	3 Decimal Point	
CSP-03	Division	1	Division size	1
		2		
		5		
		10		
		20		
		50		
CSP-04	Max. Capacity	999999 ↓ 000000	Max. capacity	999999
CSP-05	Zero range	0 =full range (±1%~30%)	Zero range = calibration zero point ± (Max. capacity×setting value %)	0
CSP-06	Time of zero tracking	0.0 ~ 5.0 (sec)	Time and range of zero tracking should be use at the same time. If the time is set to 0.0, the zero tracking function is disabled.	1.0
CSP-07	Range of zero tracking	0 ~ 9	Range of zero tracking = (setting value×½)D , D=min. division Range and time of zero tracking should be use at the same time. If the range is set to 0, the zero tracking function is disabled.	2
CSP-08	Investigate time in stable	0.0 ~ 5.0 (sec)	Investigate time and range should be use at the same time. If the time is set to 0.0, the investigate time is disabled.	1.0
CSP-09	Investigate range in stable	0 ~ 9	Investigate time and range should be use at the same time. If the range is set to 0, the investigate range is disabled.	2
CSP-10	Weight unstable, function ZERO and TARE	0	Action	0
		1	None	
CSP-11	Gross Weight is negative, function TARE	0	Action	0
		1	None	



EXCELL®

EXCELL PRECISION CO. LTD.

## 3-5 General Calibration

Set CAL switch to ON

88 888

Select General Calibration

88 888

Press the Key

8888 kg

Zero Calibration

No weight on the platform or in the hopper

Press the key

... . . . . kg

Five sec. later

8888

Two sec. later

30000 kg

### Weight Calibration

Use the front panel to key in the weight value

Place the weight on the platform or inside the hopper.

After the weight is stable

... . . . . kg

Press the key

Five sec. later

88 888

Calibration complete set calibration switch to the OFF position

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

- 4 Zero calibration only, press key to escape after the display shows 8888.
- 4 Span calibration only, press key entering directly to span calibration after the display shows EEE88.
- 4 Please refer to error message during calibration of the display show 888.X



EXCELL®

EXCELL PRECISION CO. LTD.

## 3-6 Linearity Calibration

\*\* Before the Linearity calibration, the General calibration should be completed.

Set CAL switch to ON

88 888

Select linearity calibration

88 888

Press the

ENTER Key

8.8 88

Use F1  $\wedge$  F  $\vee$  to select one of calibration points (1P~5P)

88 : no setting value  
888 : with setting value

Select one of five calibration, and

Press I/O ESC key

press the ENTER Key

888888

Press I/O ESC key

Press the ENTER Key

888999

The current shows on the screen and the indications keep flashing

Key in the correct weight value

888000

Press I/O ESC key

... . . . :

When stable, the display area shows

the modified weight value

888000

Press I/O ESC key

88 888

Finish the 1<sup>st</sup> calibration point setting. Either continue the second point calibration or

press I/O ESC key to exit the linearity calibration process.

F1 $\wedge$	⇒ Increment flashing digit
F $\vee$	⇒ Decrement flashing digit
0 ZERO <	⇒ Move flashing point left.
> TARE >	⇒ Move flashing point right
ENTER	⇒ Store data in memory
I/O ESC	⇒ Exit / Escape

4 Please refer to the error message list if the display shows 888.X

## 2 Display the setting value of linearity calibration

Set CAL switch to ON

08 888

Select linearity calibration

08 888

Press the



Key

88 888

Use **F1** **F** to select one of calibration points (1P~5P)

**88** : no setting value  
**888** : with setting value

Press the



Key

008000

Display the setting value of this calibration point

Press the



Key

88 888

Either continue to display the second point value or

press **I/O** **ESC** key to exit the linearity calibration mode

## 2 Clear the setting value of linearity calibration

Set CAL switch to ON

08 888

Select linearity calibration

08 888

Use **F1** **F** keys to select one of calibration. (1P~5P)

**00** à No setting value  
**888** à With setting value

Press the



Key

88 888

Display the setting value of this calibration point

Press the



Key

008000

Press the



Key

88 88

<b>F1</b>	⇒ Increment flashing digit
<b>F</b>	⇒ Decrement flashing digit
<b>→0← ZERO</b>	⇒ Move flashing point left.
<b>→T← TARE</b>	⇒ Move flashing point right
<b>← ENTER</b>	⇒ Store data in memory
<b>I/O ESC</b>	⇒ Exit / Escape

Either continue to clear the second point value or

press **I/O** **ESC** key to exit the linearity calibration mode

4 Please refer to the error message list if the display shows **888 E X**



EXCELL®

EXCELL PRECISION CO. LTD.

### 3-7 Digital Calibration

Set CAL switch to ON

88 888

Select Digital calibration

85 888

Press the Key

88 88

Two sec. later

000000

Method 1  
Input zero voltageMethod 2  
With no weight on the platform or in the hopper  
press the Key to set zero.

0.00036

Press the Key

8888

Two sec. later

000000

Input the span voltage

2.90000

Press the Key

888

Two sec. later

000000

Enter the weighing capacity


888888

Press the Key

85 888

Calibration completed set calibration switch to the OFF position

4 Please refer to the error message list if the display shows 888.X



**Zero Voltage** ▶ 0.00036 mV/V (incl. dead load)  
**Span Voltage** ▶ 2.90000 mV/V  
**Capacity** ▶ 30000 divisions

Zero voltage calibration.  
Two sec. later  
Input the span voltage  
Enter the weighing capacity

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape





### 3-8 Calibration Error Messages

- 888. 0 ⇒ Load Cell output voltage < - 0.1mV/V or > 4mV/V
- 888. 8 ⇒ Weight value ≤ previous weight value
- 888. 2 ⇒ Actual measured weight value ≤ previous weight value
- 888. 3 ⇒ Setting value 0
- 888. 4 ⇒ mV/V value entered > measuring range
- 888. 5 ⇒ mV/V value entered is too small (SPAN – Zero < 0 mV/V)
- 888. 6 ⇒ Displayed resolution is less than 0.12 $\mu$ V / division

# CHAPTER 4 WEIGHT COMPARISON PROCEDURES


## 4-1 Function Configuration Menu






# Functional Parameter Instruction

Item	Function	Setting value		Default
		Parameter	Description	
SQ- 01	Batching mode	1	Normal batch	1
		2	Loss-in weight	
		3	Comparison mode	
		4	Normal batch (Built-in program)	
		5	Loss-in weight (Built-in program)	
		6	Hold mode (Built-in program)	
SQ- 02	Batching start delay time	0.0 ~ 25.5 (sec)	The built-in auto-program starts the batch comparison procedure after the input of the batch start signal.	0.0
SQ- 03	SP1,SP2 Waiting time comparison	0.0 ~ 25.5 (sec)	No full flow comparison during this function's set time period. If the set value is 0, indicates this function is not in use.	0.0
SQ- 04	Batch finish output signal delay time	0.0 ~ 25.5 (sec)	Output the batch finished signal after this delay time.	0.5
SQ- 05	Batch finish Condition	0 1	Wait until the weight is stabilized No need to wait until the weight has stabilized	0
SQ- 06	Batch finish Output signal time	0.0 ~ 25.5 (sec)	Batch finished output signal time. If set to 0, the output signal will be off until the next batch start.	1.0




SQ- 07	Number of Times the supplementary loading function operates	0 ~ 255	If the set value is 0, this function is not in use.	0
SQ- 08	Supplementary loading gate open time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	0.1
SQ- 09	Supplementary loading gate close time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	1.0





Item	Function	Setting value		Default
		Parameter	Description	
SQ- 10	Discharge start delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is ON.	0.0
SQ- 11	Discharge stop delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is OFF.	0.0
SQ- 12	Discharge time	0.0 ~ 25.5 (sec)	Won't activate internal discharge control function, if set to 0.	0



SQ- 13	Restart delay time	0.0 ~ 25.5 (sec)	Delay time before Restart signal is ON.	1.0
SQ- 14	Batching counts	0 ~ 255 (times)	Number of batch runs 0 ⇒ one batch only	0
SQ- 15	Set the zero band in to final weighing value	0 1	No setting Setting	0
SQ- 16	Hi, OK, Lo	0 1 2 3 4	Comparison anytime To compare at batch finish To compare at external input signal To compare at batching finish and external input signal. Comparison auto	0
SQ- 17	Auto totalise weight / counts	0 1	Disabled Enabled	0
SQ- 18	The parameter source in weight comparison	0 1	Key in directly from front keypad Input directly from rear interface	0
SQ- 19	Weight comparison delay time	0.0 ~ 25.5 (sec)	Comparison delay time for Hi, OK, Lo	0.5
SQ- 20	TARE auto.	0 1	Press keypad TARE to TARE TARE auto	0
SQ- 21	Discharge auto	0 1	Input from external input or keypad Discharge auto + manual	0



EXCELL®

EXCELL PRECISION CO. LTD.

## 4-2 Check Weighing Configuration

### 1. FNC-04 = 1, SQ-01 = 1,2,4 or 5

Press the **F** Key →

ENTER

Display shows the existing **Final value** setting. Input new value as required.

Press

ENTER

Display shows the existing **SP1 value** setting. Input new value as required.

Press

ENTER

Display shows the existing **SP2 value** setting. Input new value as required.

Press

ENTER

Display shows the existing **Free Fall value** setting. Input new value as required.

Press

ENTER

Display shows the existing **Over value** setting. Input new value as required.

Press

ENTER

Display shows the existing **Under value** setting. Input new value as required.

Press

ENTER

Display shows the existing **Zero Band** setting. Input new value as required.

Press

F1  
^

⇒ Increment flashing digit

F  
▼

⇒ Decrement flashing digit

< 0 ←  
ZERO <

⇒ Move flashing point left.

> T ←  
TARE >

⇒ Move flashing point right

← ENTER

⇒ Store data in memory

I/O  
ESC


⇒ Exit / Escape



EXCELL®

EXCELL PRECISION CO. LTD.

## 2. FNC-04 = 1, SQ-01 = 3



	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



EXCELL®

EXCELL PRECISION CO. LTD.

### 3. FNC-04 = 1, SQ-01 = 6

Press the **F** Key →

8. 88



888888

Display shows the existing **Hi value** setting,  
Input new value as required.

Press



2. 88



888888

Display shows the existing **Lo value** setting,  
Input new value as required.

Press



3.58888



888888

Display shows the existing **Zero Band**  
setting, Input new value as required.

Press



8.8888



888888

Display show the existing **Peak Ready  
value** setting. Input new value as required

Press



8. 88

<b>F1</b>	⇒ Increment flashing digit
<b>F</b>	⇒ Decrement flashing digit
<b>→0← ZERO</b>	⇒ Move flashing point left.
<b>→T← TARE</b>	⇒ Move flashing point right
<b>←ENTER</b>	⇒ Store data in memory
<b>I/O ESC</b>	⇒ Exit / Escape



EXCELL®

EXCELL PRECISION CO. LTD.

## 4-3 Batching Signal Outputs


### 2 Normal batching signal outputs

Signal	Output condition
SP1	Net ≥ Final - SP1
SP2	Net ≥ Final - SP2
SP3	Net ≥ Final – Free Fall (in-flight)
Under	Net < Final – Under
Over	Net > Final + Over
Zero Band	Gross ≤ Zero Band


### 2 Loss-in-weight signal outputs

Signal	Output condition
SP1	Gross ≥ SP1
SP2	- Net ≥ Final – SP2
SP3	- Net ≥ Final – Free Fall (in-flight)
Under	- Net < Final – Under
Over	- Net > Final + Over
Zero Band	Gross ≤ Zero Band

## 4-4 Normal Batching Flow Chart (SQ-01=1)




## 4-5 Loss-in Weight Flow Chart ( SQ1 = 2 )







## 4-6 Hi, OK, Lo Output Flow Chart



## 4-7 Normal Batching (Built-in Program) Flow Chart (SQ-01=4)




## 4-8 Loss-in Weight (Built in Program) (SQ-01=5)




## 4-9 Hold Mode (SQ-01 = 6)

### 1. General hold mode (FNC-11 = 0)



### 2. Peak hold mode ( FNC-11 = 1, 2 )




Peak hold mode with four different states ( FNC-11 = 1,2,3,4 ), positive peak weight(1), negative peak weight, absolute value of peak weight and positive peak weight(2) . The peak holds of absolute value and positive peak weight (2) both have no peak ready signal output.



EXCELL® EXCELL PRECISION CO. LTD.

## 4-9-1 Hold Mode Flow Chart





## 4-9-2 Hi, OK, Lo Comparison

### 1. Normal HOLD ( FNC-11 = 0 )

Entering the Hold mode, Hi, OK, Lo comparison output. Escape Hold mode will switch off the outputs.

### 2. Peak HOLD ( FNC-11 = 1, 2 )

If Peak Ready is ON, Hi, OK, Lo comparison output. Escape Hold mode will switch off the outputs.

### 3. The absolute value of peak HOLD ( FNC-11 = 3 )

Entering the Hold mode, Hi, OK, Lo will refer to Peak value to do the comparison.

### 4. FNC-11 = 4

When the external input single Judgement is ON, Hi, OK, Lo will refer to Peak value to do the comparison.

## 4-10 Totalizing (ACCU.) Auto / Transmit

With automatic totalising active (SQ-17) or RS232 / RS485 or BCD output set to auto transmit.

### 1. SQ-01 = 1, 2, 4 or 5 batch / loss-in weight

- When the weight reaches the Final weight and the batch finish signal is ON the net weight will be added to the totaliser and number of additions is incremented. The RS232 / RS485 and BCD outputs transmit data.
- When the net weight returns to the zero range (FNC-10), then the sequence in a) above can be repeated.

### 2. SQ-01 = 3 Comparison mode

- When the net weight exceeds the zero range and the weight has stabilized it will be added to the totaliser and number of additions is incremented. The RS232 / RS485 and BCD outputs transmit data.




EXCELL®

EXCELL PRECISION CO. LTD.


# CHAPTER 5 INTERFACE

## 5-1 Serial Input/Output Interface (Built-in) 2 Pin location and setting

### 1. Built-in RS232 or RS485




PIN	Function
5	TXD / DA -
6	RXD / DA +
7	SG



## 2 Connection type

### RS-485



- Notice:

- The maximum connection is 10 sets of EX-2005
- When the Host computer has the built-in terminal resist, it is not necessary to have the external one.
- When the host computer has no single (SG), it is acceptable to disconnect that part.




EXCELL®

EXCELL PRECISION CO. LTD.

## 2 Function setting

First serial port interface 88 898  
Setting procedure



	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



EXCELL®

EXCELL PRECISION CO. LTD.

Item	Function	Setting Value		Default
		Para-meter	Description	
RS1- 01	Transmit format	0	As display	0
		1	Gross only	
		2	Net only	
		3	As display (simple)	
		4	Gross (simple)	
		5	Net (simple)	
		6	Comparison + As display (simple)	
		7	Comparison +Gross (simple)	
		8	Comparison +Net (simple)	
		9	Tare	
RS1- 02	Transmit mode	10	Totalised (Accu.) Weight and number of transactions	0
		0	Transmit continuous + command mode	
		1	Auto transmit + command mode	
		2	Manual transmit + command mode	
		3	Command mode	
RS1- 03	Transmit speed	4	MODBUS RTU mode	2
		0	600	
		1	1200	
		2	2400	
		3	4800	
		4	9600	
RS1- 04	Parity Bit length Stop Bit	5	19200	2
		0	N, 8, 1	
		1	O, 7, 1	
RS1- 04	MODBUS mode: Parity Bit length Stop Bit	2	E, 7, 1	2
		0	N, 8, 2	
		1	O, 8, 1	
RS1- 05	Transmit times	2	E, 8, 1	0
		0	Open	
		1	1 time/sec.	
		2	2 time/sec.	
		3	5 time/sec.	
RS1- 06	Transmission conditions	4	10 time/sec.	000000
		0 0 0 0 0 0	0 ⇒ transmit cont. 1 ⇒ Stop transmit	
RS1- 07	Indicator poling address	↓	Negative(Net Wt.) Weight unstable Overload (OL)	000000
		99	When set to 0, Indicator addressing is not used.	



EXCELL®

EXCELL PRECISION CO. LTD.

## 2 Data format

### 1. General Format

NET	S	T	,	G	S	,	+	0	1	2	3	4	5	6	k	g	CR	LF
GROSS	S	T	,	N	T	,	+	1	2	3	4	.	5	6		g		
TARE	S	T	,	T	R	,	+	0	1	2	3	4	5	6		t		
+ OL	O	L	,	G	S	,	+	SP										
- OL	O	L	,	G	S	,	-	SP										
UNSTABLE	U	S	,	G	S	,	+	1	2	3	4	.	5	6	k	g		


### 2. Totalised (Accu.) Format

Accu. Weight	T	W	,	+	1	2	3	4	5	6	.	7	8	9	k	g	CR	LF
Accu. Wt. Over+	T	W	,	+	SP													
Accu. Wt. Over -	T	W	,	-	SP													
Accu. Count	T	N	,	+	0	1	2	3	4	5	6	7	8	9	SP	SP		
Accu. Count over	T	N	,	+	SP													

### 3. Simple Format

Gross/Net or same display	+	1	2	3	4	5	6	7	CR	LF
Over load positive	+	SP								
Over load negative	-	SP								

### 4. Setpoint (1) + Simple Format (Gross/Net or as display)



- bit 0 : Zero Band
- bit 1 : Over
- bit 2 : Under / Hi
- bit 3 : SP1 / Go
- bit 4 : SP2 / Lo
- bit 5 : SP3
- bit 6 : Discharge
- bit 7 : Batch finished



## 5. Comparison condition (2)

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
--------	--------	--------	--------	--------	--------	--------	--------

Byte 0 : Zero Band

Byte 1 : Over

ON : 0 ( ASC II Code 30 H )

Byte 2 : Under / Hi

OFF : 1 ( ASC II Code 31 H )

Byte 3 : SP1 / Go

Byte 4 : SP2 / Lo

Byte 5 : SP3

Byte 6 : Discharge

Byte 7 : Batch finished

### Description

	Output	ASCII	Description
Status 1	OL	4FH, 4CH	Over load
	ST	53H, 54H	Weight stable
	US	55H, 53H	Weight unstable
Status 2	GS	47H, 53H	Gross Weight
	NT	45H, 54H	Net Weight
	TR	54H, 52H	TARE
	TW	54H, 57H	Totalised Weight
	TN	54H, 4EH	Totalised Times
Data of Weight	0 ~ 9	30H ~ 39H	Figure of weight
	+, -	2BH, 2DH	Symbol (+ or -) of weight
	Space	20H	Over load
	.	2EH	Decimal
	Space, Space	20H, 20H	None
Units	kg	6BH, 67H	kg
	Space t	20H, 74H	ton
	lb	6CH, 62H	lb
	Ending code	0DH, 0AH	Ending code
Separating code	,	2CH	



EXCELL®

EXCELL PRECISION CO. LTD.

## 2 Command mode

### 1. Command Format A

Host      **Command** <CR><LF>Slave                    **Command** <CR><LF>

MZ	Zero	CZ	Zero compensation On/OFF
MT	Tare	CT	Clear TARE value
MG	Gross Weight	MN	Net weight
AT	Accu. Current net weight and times plus 1.		
ST	Deduct times of last accu. Value minus 1		
DT	Clear accu. Value and times		
BB	Start batching (one time)	HB	Load stop
BD	Start unload		
SC	Transmit continuous	SA	Auto transmit
SM	Manual transmit	SO	Command mode
%	Stop continuous transmission and enter the command mode		

### 2. Command Format B

Host      **Command** <CR><LF>Slave                    **Data** <CR><LF>

RW	Read current weight	RT	Read TARE
RG	Read Gross Weight	RN	Read Net weight
RB	Read current display of wt (simple)	RH	Read Gross (simple)
RI	Read Net (simple)		
RJ	Read comparison situation + current display of weight (simple)		
RK	Read comparison situation + Gross (simple)		
RL	Read comparison situation + Net (simple)		
RO	Read comparison situation (2)		
RF	Read prior completed weight	RA	Read accu. Value (incl. times)

**Note : Prior command plus %**

Read Weight Compared value: RS□□ □□: Setting items

FW	Read target item of unload value	S1	Read SP1
S2	Read SP2	S3	Read SP3
UD	Read Under	LO	Read LO
ZB	Read Zero Band	HI	Read HI
PR	Reading Peak value	OV	Read Over

**Ex:**

Command : RSFW < CR > < LF >

EX2005 reply : RSFW□□□□□□

 Finish 6 bytes



### 3. COMMAND FORMAT C

Host	Command + Data<CR><LF>
Slave	Command + Data<CR><LF>

Write weight compared value                    WS□□XXXXXX

XXXXXX : value (6 bytes)                    □□ : Setting items

FW	Write target item of unload value	S1	Write SP1
S2	Write SP2	S3	Write SP3
UD	Write Under	LO	Write LO
ZB	Write Zero Band	HI	Write HI
PR	Write Peak value	OV	Write Over

## 2 Error messages

E1: Format command fault

E2: Setting parameters over range

E3: Command not recognised

## 2 Indicator poling address

If the indicator has an address configured in RS1 – 07 as 0, it will directly respond to the command.

If the indicator has an address configured in RS1-07 as 1~99, it will only respond to the messages prefixed the address.


For example: The indicator poling address is set to 02, it would send the weight value only if it received the command:

@02RW < CR > < LF >

## 5-2 BCD Parallel Output Interface (OP-02)


### 2 PIN Location

D-Sub 37PIN



<b>PIN</b>	<b>Function</b>	<b>PIN</b>	<b>Function</b>
1	SG	20	SG
2	$1 \times 10^0$	21	$2 \times 10^0$
3	$4 \times 10^0$	22	$8 \times 10^0$
4	$1 \times 10^1$	23	$2 \times 10^1$
5	$4 \times 10^1$	24	$8 \times 10^1$
6	$1 \times 10^2$	25	$2 \times 10^2$
7	$4 \times 10^2$	26	$8 \times 10^2$
8	$1 \times 10^3$	27	$2 \times 10^3$
9	$4 \times 10^3$	28	$8 \times 10^3$
10	$1 \times 10^4$	29	$2 \times 10^4$
11	$4 \times 10^4$	30	$8 \times 10^4$
12	$1 \times 10^5$	31	$2 \times 10^5$
13	$4 \times 10^5$	32	$8 \times 10^5$
14	Gross / - Net	33	Stable / - MD
15	Plus / - Minus	34	DP1
16	DP2	35	DP3
17	DP4	36	Over / - Normal
18	Data ready	37	Hold input
19			

### 2 Equivalent Circuit




Open Collector Output (OP-02-1)

TTL Output (OP-02-2)

Hold Input

## 2 Function setting




	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Item	Function	Setting value		Default
		Parameter	Description	
bCd- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
bCd- 02	Transmit mode	0	Transmit continuous	0
		1	Auto transmit	
		2	Manual transmit	
bCd- 03	Output Logic	0	Positive logic action	0
		1	Negative logic action	
bCd- 04	Data ready Signal logic	0	Positive logic action	0
		1	Negative logic action	
bCd- 05	OL output code	0	FFFFFF	0
		1	999999	
bCd- 06	Data code	0	BCD Code	0
		1	Hex. Code	

## 5-3 Analogue Current Output Interface (OP-03)

### 2 Location



#### A. Terminal (4 way)

- 1<sup>st</sup> : 0 ~ 20mA current output, positive
- 2<sup>nd</sup> : 0 ~ 10V voltage output, positive (not support)
- 3<sup>rd</sup> : Current signal, negative
- 4<sup>th</sup> : Ground

Note: For the voltage output, add a proper resistor value between A(+) and Com(-).

\* Formula for the resistor value

$$\text{Resistor value} = \frac{\text{Voltage output (max. value)}}{\text{Current output (max. value)}}$$

Example: Convert 0~20mA current output into 0~10V voltage

$$\text{Resistor value} = \frac{10 \text{ V}}{0.02 \text{ A}} = 500 \Omega$$

#### B. SPAN adjustment

Current / voltage Span adjustment to increase value turn clockwise, decrease value turn anticlockwise.

#### C. ZERO adjustment


Current / voltage Zero adjustment to increase value turn clockwise, decrease value turn anticlockwise.

### 2 Analogue output interface specification

Resolution : 16 bits

Current output : 0 ~ 20mA ( 0 ~ 550 Ω load)

## 2 Function setting



	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Item	Function	Setting value		Default
		Parameter	Description	
AnL- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
AnL- 02	Signal output	0	Current output	0
AnL- 03	Weight in Lo	000000 ~ 999999	When the weight reaches the value of that in AnL-03, the current / voltage output is changed to that configured in AnL-04.	0
AnL- 04	Current in Lo	0.0 mA ~ 20.0 mA		
AnL- 05	Weight in Hi	000000 ~ 999999	When the weight reaches the value of that in AnL-05, the current / voltage output is changed to that configured in AnL-06.	300000
AnL- 06	Current in Hi	0.0 mA ~ 20.0 mA		




## 2 Analogue output notes

1. The current output, load resistor should not exceed  $550\ \Omega$ . It is recommended that a resistor with a low temperature coefficient and a power rating above 0.2 W be used.
2. Avoid short circuits between the positive and negative analogue output terminals as the interface this may cause damage.

## 5-4 External Parallel Input /Output Interface

### 2 PIN location

D-Sub 37PIN




### 2 OP-04 Control I/O (4 in / 4 out) + Setpoint Input (BCD code)

PIN	I/O	Signal	PIN	I/O	Signal
1	IN	Code 100	20	IN	Code 101
2	IN	Code 102	21	IN	Code 103
3	IN	Code 104	22	IN	Code 105
4	IN	Code 106	23	IN	Code 107
5	IN	Code 108	24	IN	Code 109
6	IN	Code 1010	25	IN	Code 1011
7			26		
8			27	OUT	OUT 1
9	OUT	OUT 2	28	OUT	OUT 3
10	OUT	OUT 4	29	IN	Vex
11		COM 2	30		COM 2
12			31		
13		COM 1	32		COM1
14	IN	IN 1	33	IN	IN 2
15	IN	IN 3	34	IN	IN 4
16			35		
17			36	IN	Code 1
18	IN	Code 2	37	IN	Code 4
19	IN	Code 8			

### 2 OP-05 Control I/O (8 in / 8 out)

PIN	I/O	Signal	PIN	I/O	Signal
1	IN	IN 1	20		COM 1
2	IN	IN 2	21		COM 1
3	IN	IN 3	22		COM 1
4	IN	IN 4	23		COM 1
5	IN	IN 5	24		COM 1
6	IN	IN 6	25		COM 1
7	IN	IN 7	26		COM 1
8	IN	IN 8	27		COM 1
9		COM 1	28		COM 1
10		COM 2	29		COM 2
11	OUT	OUT 1	30		COM 2
12	OUT	OUT 2	31		COM 2
13	OUT	OUT 3	32		COM 2
14	OUT	OUT 4	33		COM 2
15	OUT	OUT 5	34		COM 2
16	OUT	OUT 6	35		COM 2
17	OUT	OUT 7	36		COM 2
18	OUT	OUT 8	37		COM 2
19	IN	Vex			


## 2 Input signal configuration



	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Item	Function	Setting value			Default
		Parameter	P	Description	
IN - 01	Input 1	0	⇒ None		1
		1	⇒ Zero		
IN - 02	Input 2	2	⇒ Tare		2
		3	⇒ Tare reset		
IN - 03	Input 3	4	⇒ Start batching		3
		5	⇒ Stop batching		
IN - 04	Input 4	6	⇒ Discharge Command		4
		7	⇒ Hold		
IN - 05	Input 5	8	⇒ Hold display & I/O reset		5
		9	⇒ Totalise (Accu) Command		
IN - 06	Input 6	10	⇒ Clear totaliser (Accu)		6
		11	⇒ Clear previous total (Accu) Value.		
IN - 07	Input 7	12	⇒ Start to compare		7
		13	⇒ Serial and parallel printer manual output		
IN - 08	Input 8	14	⇒ Net / Gross		8


## 2 Output signal setting



<b>F1</b>	⇒ Increment flashing digit
<b>F</b>	⇒ Decrement flashing digit
<b>→0 ← ZERO</b>	⇒ Move flashing point left.
<b>→T ← TARE</b>	⇒ Move flashing point right
<b>← ENTER</b>	⇒ Store data in memory
<b>I/O</b>	⇒ Exit / Escape
<b>ESC</b>	

Item	Function	Setting value		Default
		Parameter	Description	
OUT- 01	Output 1	0	⇒ None	1
		1	⇒ Zero band	
OUT- 02	Output 2	2	⇒ SP1	2
		3	⇒ SP2	
OUT- 03	Output 3	4	⇒ SP3	3
		5	⇒ Batching completed	
OUT- 04	Output 4	6	⇒ Discharge	4
		7	⇒ Peak ready	
OUT- 05	Output 5	8	⇒ Stable	5
		9	⇒ Internal batching process running	
OUT- 06	Output 6	10	⇒ Under	6
		11	⇒ Over	
OUT- 07	Output 7	12	⇒ Hi	7
		13	⇒ OK	
OUT- 08	Output 8	14	⇒ Lo	8
OUT-09	The output logic of OUT-04~OUT-01	0000	à positive logic 1111 à negative logic	0000
OUT-10	The output logic of OUT-08~OUT-05	0000	à positive logic 1111 à negative logic	0000


## 2 Equivalent Circuits



**4** IN 1 ~ IN 8 and COM 1. Input signal - Open  $\leftrightarrow$  OFF, Short  $\leftrightarrow$  ON.

**4** Warning: Don't use external power (AC or DC) to connect to the input terminals.

### Output



## 2 Thumbwheel Switches (for OP-04)


The interface can connect to external thumbwheel switches or a PLC to input various parameters depending on the configuration of SQ-01. The input variables are:-

- Final (5 digits), SP2 (4 digits) & Free Fall (3 digits)  
or , Hi (6 digits), Lo (6 digits)


When using external thumbwheel Switches, SQ-18 should be set to 1.

## Connection data

**SQ-01 = 1, 2, 4 or 5**



**SQ-01 = 3 or 6**






# CHAPTER 6 MAINTENANCE

## 6-1 Restore all Parameters to The Default Factory Values.

- (1) While the indicator is counting back to zero, adjust SW to ON and press
- (2) Display shows the flashing digits
- (3) Confirm / abort
  - (3-1) To confirm press key & don't release it until the display shows
  - (3-2) To abort, set the calibration SW to OFF directly.

## 6-2 Maintenance Function Parameters

Power on the machine. Press keys while the display counts back to zero.





EXCELL®

EXCELL PRECISION CO. LTD.

## 6-2-1 Restore the Function Parameter Back to Its Default Value

(1) During the indicator count back to zero, press

(2) The display shows

(3) Press key and the display shows flashing.

(4) Confirm / abort

(4-1) To confirm, press the key & don't release it. The display will then show

(4-2) To abort press the key or switch the power off.

## 6-2-2 Clear Zero Compensation and Tare Values

(1) During the indicator count back to zero, press

(2) The display shows press the F1 key to display

(3) Press key, the display shows flashing.

(4) Confirm / abort

(4-1) To confirm press the key & don't release it. The display will then show

(4-2) To abort press the key or switch the power off.

## 6-2-3 Clear Batch Setting

(1) During the indicator count back to zero, press

(2) The display shows press the F1 key to display

(3) Press key, the display shows flashing.

(4) Confirm / abort

(4-1) To confirm press the key & don't release it. The display will then show

(4-2) To abort press the key or switch the power off.

## 6-2-4 Display Zero Voltage (mV/V)

(1) During the indicator count back to zero, press

(2) The display shows press the F1 key to display

(3) Press key the display shows the zero voltage (mV/V). e.g.

(4) Press key or switch the power off.



EXCELL®

EXCELL PRECISION CO. LTD.

## 6-2-5 Clear Batch Setting

(1) During the indicator count back to zero, press


(2) The display shows press the F1 key to display

(3) Press the key, the display shows the span voltage (mV/V).  
e.g.

(4) Press key or switch the power off.

## 6-3 Test Mode

During the indicator count back to zero





EXCELL®

EXCELL PRECISION CO. LTD.

### 6-3-1 7 Segment Display Testing

The display will show 0 ~ 9, then display “.” and all of the icons. To exit press

### 6-3-2 Keypad and Calibration SW Testing

Setting the calibration SW to “ON”, or pressing any key will cause the related display segment to change from 1 → 1. To exit press

### 6-3-3 Display A/D Internal Value Display

Display range is 0 ~ 520,000d (-0.1mV/V ~ 4.0mV/V). To exit press

### 6-3-4 RS-232 Serial Loop Back Testing

Terminal pin 5 and pin 6 must be connected together at the rear of the indicator.

If display shows 8888, the interface is working normally. If display shows 8888, the interface is not working correctly.

### 6-3-5 EEPROM Memory Testing

If the display shows 8888, it means normal. If the display shows 8888, the memory is not working correctly.

### 6-3-6 Option Interface Card Testing

#### 2 OP-02 BCD parallel output interface testing

- 1) A flashing decimal point indicates the test procedure is active.
- 2) Program will transmit OFF → ON → OFF signal for each output bit of the BCD interface in sequence.

#### 2 OP-03 Analogue current output interface testing

##### 4 ~ 20mA current output testing

Use an ammeter to measure the output current between pin1 & pin 3 of the interface.

Use the keys to select the output current level desired.


8.888	⇒	4mA
8.888	⇒	12mA
8.888	⇒	20mA



EXCELL®

EXCELL PRECISION CO. LTD.


## 2 OP-04 Control I/O (4I/4O) testing








2) Press key to switch to the control input value.

Input 1 ~ 4 signal ON/OFF, related to display →

## 2 OP-05 Control I/O (8I/8O) testing



# APPENDIX I DESCRIPTION OF 7 SEGMENT CHARACTERS

Digit	7 segments letter	Alphabet	7 segments letter	Alphabet	7 segments letter
0		A		N	
1		B		O	
2		C		P	
3		D		Q	
4		E		R	
5		F		S	
6		G		T	
7		H		U	
8		I		V	
9		J		W	
		K		X	
		L		Y	
		M		Z	



EXCELL®

EXCELL PRECISION CO. LTD.

## APPENDIX II FUNCTION TABLE

### Specification Calibration

Item	Function		Setting Value	Default
		Parameter	Description	
CSP-01	Unit	0	None	2
		1	g	
		2	Kg	
		3	t	
		4	lb	
CSP-02	Decimal Point	0	None	0
		1	1 Decimal Point	
		2	2 Decimal Point	
		3	3 Decimal Point	
CSP-03	Division	1	Division	1
		2		
		5		
		10		
		20		
		50		
CSP-04	Max. Capacity	999999 ↓ 000000	Max. capacity	999999
CSP-05	Zero range	0 =full range (±1%~30%)	Zero range = calibration zero point ± (Max. capacity×setting value %)	0
CSP-06	Time of zero tracking	0.0 ~ 5.0 (sec)	Time and range of zero tracking should be use at the same time. If the time is set to 0.0, the zero tracking function is disabled.	1.0
CSP-07	Range of zero tracking	0 ~ 9	Range of zero tracking = (setting value×½)D , D=min. division Range and time of zero tracking should be use at the same time. If the range is set to 0, the zero tracking function is disabled.	2
CSP-08	Investigate time in stable	0.0 ~ 5.0 (sec)	Investigate time and range should be use at the same time. If the time is set to 0.0, the investigate time is disabled.	1.0
CSP-09	Investigate range in stable	0 ~ 9	Investigate time and range should be use at the same time. If the range is set to 0, the investigate range is disabled.	2
CSP-10	Weight unstable, function ZERO and TARE	0	Action	0
	1	None		
CSP-11	Gross Weight is negative, function TARE	0	Action	0
	1	None		



EXCELL®

EXCELL PRECISION CO. LTD.

## 2 FNC Group Function Setting

Item	Function	Setting value			Default	
		Parameter	Description			
FNC-01	Digital Filter I	0	5 Hz		4	
		1	4.17 Hz			
		2	2.5 Hz			
		3	2.08 Hz			
		4	1.25 Hz			
		5	1.04 Hz			
		6	0.63 Hz			
		7	0.52 Hz			
		8	0.31 Hz			
		9	0.26 Hz			
FNC-02	Digital Filter II	0	Disabled		2	
		1	Less filter			
		2				
		3				
		4				
		5	Greater			
FNC-03	Key – Locked	000000 ↓ 111111	0 1	Normal (lock disable) Close (lock enable)	The bits and front panel key positions are related to each other. 000000	
FNC-04	“F” function setting	Parameter ⇒ Description 0 ⇒ Display Net / Gross weight 1 ⇒ Setpoint parameter setting 2 ⇒ Tare reset 3 ⇒ Manual serial, parallel print output. 4 ⇒ Start load 5 ⇒ Stop load 6 ⇒ Start comparison 7 ⇒ Unload command 8 ⇒ Totalise weight and counts command 9 ⇒ Clear totalised weight and counts 10 ⇒ Hold mode 11 ⇒ Escape Hold mode (I/O DSP) 12 ⇒ Convert to Gross / Net / totalised weight / totalised Count				
FNC-05	“F1” function setting					



EXCELL®

EXCELL PRECISION CO. LTD.


Item	Function	Setting value		Default
		Parameter	Description	
FNC-06	Front panel indication “◀” setting (top)	Parameter ⇒ Description		
		0	⇒ Zero	0
		1	⇒ MD	
		2	⇒ Gross	
		3	⇒ Net	
		4	⇒ Totalised weight (Accu. V)	
FNC-07	Front panel indication “◀” setting (next to top)	5	⇒ Totalised transactions (Accu. C)	1
		6	⇒ SP1	
		7	⇒ SP2	
		8	⇒ SP3	
FNC-08	Front panel indication “◀” setting (next to bottom)	9	⇒ Hi	2
		10	⇒ OK	
		11	⇒ Lo	
		12	⇒ Under	
FNC-09	Front panel indication “◀” setting (bottom)	13	⇒ Over	
		14	⇒ Discharge	3
		15	⇒ Running	
		16	⇒ Hold	
FNC-10	Return to zero band	0	5 d	
		1	10 d	
		2	20 d	
		3	40 d	
		4	60 d	
		5	80 d	0
		6	100 d	
		7	150 d	
		8	200 d	
		9	250 d	
FNC-11	Hold	0	Hold	
		1	Peak hold (positive 1)	
		2	Peak hold (negative)	
		3	Peak hold (absolute value)	0
		4	Peak hold (positive 2)	
FNC-12	Rate for display rewrite	0	No limitation	
		1	20 times/sec	
		2	10 times/sec	
		3	5 times/sec	0
		4	1 time/sec	



EXCELL®

EXCELL PRECISION CO. LTD.

## Serial Input/Output Interface (Build in)

Item	Function	Setting Value		Default
		Parameter	Description	
RS1- 01	Transmit format	0	As display	0
		1	Gross only	
		2	Net only	
		3	As display (simple)	
		4	Gross (simple)	
		5	Net (simple)	
		6	Comparison + As display (simple)	
		7	Comparison +Gross (simple)	
		8	Comparison +Net (simple)	
		9	Tare	
		10	Totalised (Accu.) Weight and number of transactions	
RS1- 02	Transmit mode	0	Transmit continuous + command mode	0
		1	Auto transmit + command mode	
		2	Manual transmit + command mode	
		3	Command mode	
		4	MODBUS RTU mode	
RS1- 03	Transmit speed	0	600	2
		1	1200	
		2	2400	
		3	4800	
		4	9600	
		5	19200	
RS1- 04	Parity Bit length Stop Bit	0	N, 8, 1	2
		1	O, 7, 1	
		2	E, 7, 1	
RS1- 04	MODBUS mode: Parity Bit length Stop Bit	0	N, 8, 2	2
		1	O, 8, 1	
		2	E, 8, 1	
RS1- 05	Transmit times	0	Open	0
		1	1 time/sec.	
		2	2 time/sec.	
		3	5 time/sec.	
		4	10 time/sec.	
RS1- 06	Transmission conditions	0 0 0 0 0 0		000000
		 Negative(Net Wt.) Weight unstable Overload (OL)		
RS1- 07	Indicator poling address	00 ↓ 99	When set to 0, Indicator addressing is not used.	0



EXCELL®

EXCELL PRECISION CO. LTD.

## BCD Parallel Output Interface (OP – 02)

Item	Function	Setting value		Default
		Parameter	Description	
bCd- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
bCd- 02	Transmit mode	0	Transmit continuous	0
		1	Auto transmit	
		2	Manual transmit	
bCd- 03	Output Logic	0	Positive logic action	0
		1	Negative logic action	
bCd- 04	Data ready	0	Positive logic action	0
	Signal logic	1	Negative logic action	
bCd- 05	OL output code	0	FFFFFF	0
		1	999999	
bCd- 06	Data code	0	BCD Code	0
		1	Hex. Code	



EXCELL®

EXCELL PRECISION CO. LTD.

## Analogue Current/Voltage Output Interface (Op - 03)

Item	Function	Setting value		Default
		Parameter	Description	
AnL- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
AnL- 02	Signal output	0	Current output	0
AnL- 03	Weight in Lo	000000 ~ 999999	When the weight reaches the value of that in AnL-03, the current / voltage output is changed to that configured in AnL-04.	0
AnL- 04	Current / Voltage in Lo	0.0 mA ~ 20.0 mA		
AnL- 05	Weight in Hi	000000 ~ 999999	When the weight reaches the value of that in AnL-05, the current / voltage output is changed to that configured in AnL-06.	300000
AnL- 06	Current / Voltage in Hi	0.0 mA ~ 20.0 mA		



## External Parallel Input/Output Interface (Op-04 & Op-05)

Item	Function	Setting value		Default
		Parameter	⇒ Description	
IN - 01	Input 1	0	⇒ None	1
		1	⇒ Zero	
IN - 02	Input 2	2	⇒ Tare	2
		3	⇒ Tare reset	
IN - 03	Input 3	4	⇒ Start batching	3
		5	⇒ Stop batching	
IN - 04	Input 4	6	⇒ Discharge Command	4
		7	⇒ Hold	
IN - 05	Input 5	8	⇒ Hold display & I/O reset	5
		9	⇒ Totalise (Accu) Command	
IN - 06	Input 6	10	⇒ Clear totaliser (Accu)	6
		11	⇒ Clear previous total (Accu) Value.	
IN - 07	Input 7	12	⇒ Start to compare	7
		13	⇒ Serial and parallel printer manual output	
IN - 08	Input 8	14	⇒ Net / Gross	8

Item	Function	Setting value		Default
		Parameter	Description	
OUT- 01	Output 1	0	⇒ None	1
		1	⇒ Zero band	
OUT- 02	Output 2	2	⇒ SP1	2
		3	⇒ SP2	
OUT- 03	Output 3	4	⇒ SP3	3
		5	⇒ Batching completed	
OUT- 04	Output 4	6	⇒ Discharge	4
		7	⇒ Peak ready	
OUT- 05	Output 5	8	⇒ Stable	5
		9	⇒ Internal batching process running	
OUT- 06	Output 6	10	⇒ Under	6
		11	⇒ Over	
OUT- 07	Output 7	12	⇒ Hi	7
		13	⇒ OK	
OUT- 08	Output 8	14	⇒ Lo	8
OUT- 09	The output logics of OUT-04~OUT-01	0000 à positive logic 1111 à negative logic		0000
OUT- 10	The output logics of OUT-08~OUT-05	0000 à positive logic 1111 à negative logic		0000



EXCELL®

EXCELL PRECISION CO. LTD.

Item	Function	Setting value		Default
		Parameter	Description	
SQ- 01	Batching mode	1	Normal batch	1
		2	Loss-in weight	
		3	Comparison mode	
		4	Normal batch (Built-in program)	
		5	Loss-in weight (Built-in program)	
		6	Hold mode (Built-in program)	
SQ- 02	Batching start delay time	0.0 ~ 25.5 (sec)	The built-in auto-program starts the batch comparison procedure after the input of the batch start signal.	0.0
SQ- 03	SP1,SP2 Waiting time comparison	0.0 ~ 25.5 (sec)	No full flow comparison during this function's set time period. If the set value is 0, indicates this function is not in use.	0.0
SQ- 04	Batch finish output signal delay time	0.0 ~ 25.5 (sec)	Output the batch finished signal after this delay time.	0.5
SQ- 05	Batch finish Condition	0	Wait until the weight is stabilized	0
		1	No need to wait until the weight has stabilized	
SQ- 06	Batch finish Output signal time	0.0 ~ 25.5 (sec)	Batch finished output signal time. If set to 0, the output signal will be off until the next batch start.	1.0
<p><b>Batch finish signal</b></p>				
SQ- 07	Number of Times the supplementary loading function operates	0 ~ 255	If the set value is 0, this function is not in use.	0
SQ- 08	Supplementary loading gate open time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	0.1
SQ- 09	Supplementary loading gate close time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	1.0
<p><b>Supplementary loading signal</b></p> <p>SQ- 07 Times of "ON" of the supplementary loading</p>				



## Function Configuration Menu

Item	Function	Setting value		Default
		Parameter	Description	
SQ- 10	Discharge start delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is ON.	0.0
SQ- 11	Discharge stop delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is OFF.	0.0
SQ- 12	Discharge time	0.0 ~ 25.5 (sec)	Won't activate internal discharge control function, if set to 0.	0
<p>The diagram illustrates the timing sequence for the discharge function. A 'Discharge input signal' pulse triggers the internal logic. The 'Weight reach zero band' is indicated by a horizontal line. The logic consists of two stages: 'SQ- 10' (represented by a double-headed arrow) and 'SQ- 11' (also represented by a double-headed arrow). The 'Discharge output signal' is active during the overlap of the two stages.</p>				
SQ- 13	Restart delay time	0.0 ~ 25.5 (sec)	Delay time before Restart signal is ON.	1.0
SQ- 14	Batching counts	0 ~ 255 (times)	Number of batch runs 0 ⇒ one batch only	0
SQ- 15	Set the zero band in to final weighing value	0 1	No setting Setting	0
SQ- 16	Hi, OK, Lo	0 1 2 3 4	Comparison anytime To compare at batch finish To compare at external input signal To compare at batching finish and external input signal. Comparison auto	0
SQ- 17	Auto accu. weight / counts	0 1	Disabled Enabled	0
SQ- 18	The parameter source in weight comparison	0 1	Key in directly from front keypad Input directly from rear interface	0
SQ- 19	Weight comparison delay time	0.0 ~ 25.5 (sec)	Comparison delay time for Hi, OK, Lo	0.5
SQ- 20	TARE auto.	0 1	Press keypad TARE to TARE TARE auto	0
SQ- 21	Discharge auto	0 1	Input from external input or keypad Discharge auto + manual	0



## APPENDIX III MODBUS DATA ADDRESS TABLE

Data Register		Bit I/O		Bit I/O	
Modbus	SCALE	Modbus	SCALE Output	Modbus	SCALE Input
40000 ~ 40001	As display value	00000	Stable status	01000	Zero
40002 ~ 40003	Gross weight	00001	Zero status	01001	Clear zero compensation
40004 ~ 40005	Net weight	00002	Gross	01002	Tare
40006 ~ 40007	Tare value	00003	Net	01003	Clear tare
40008 ~ 40009	Gross weight hold value			01004	Clear pre-tare
40010 ~ 40011	Net weight hold value	00050	Zero Band	01005	Display the gross weight on main display
40012 ~ 40013	Weight final value	00051	Sp1	01006	Display the net weight on main display
40014 ~ 40015	Unit weight	00052	Sp2	01007	Enter/Exit the function mode
40016 ~ 40017	Percentage value	00053	Sp3	01008 ~ 01027	Switch from the 1 <sup>st</sup> to 20 <sup>th</sup> unit
40018 ~ 40019	Totalised value	00054	Batch Finish		
40020 ~ 40021	Totalised times	00055	Under	01049	Switch the operation modes
40022 ~ 40023	Totalised times of HI value	00056	Over	01050	Totalised the current net weight and add 1 to the totalised times
40024 ~ 40025	Totalised times of LO value	00057	Discharging	01051	Deduct the last totalised value and deduct 1 to the totalised times
40026 ~ 40027	Totalised times of OK value	00058	Hi-Hi	01052	Clear the totalised value and times
		00059	Hi	01053	Running
		00060	Go	01054	Stop
		00061	Lo	01055	Discharge starts
41000 ~ 41001	Pre-tare value	00062	Lo-Lo	01056	Hold mode ON/OFF
41002 ~ 41003	Zero band value	00063	Peak ready	01057	Release "Hold value"
41004 ~ 41005	Target value	00064	Running	01058	Output judgement
41006 ~ 41007	SP1 value	00065	ZERO calibration	01059	ZERO calibration
41008 ~ 41009	SP2 value	00066	SPAN calibration	01060	SPAN calibration
41010 ~ 41011	SP3 value	00067	Calibrate ERR0		
41012 ~ 41013	LO_LO value	00068	Calibrate ERR2		
41014 ~ 41015	LO value	00069	Calibrate ERR6		
41016 ~ 41017	HI_HI value				
41018 ~ 41019	HI value				
41020 ~ 41021	Under value				
41022 ~ 41023	Over value				
41024 ~ 41025	Peak value setting				
41100 ~ 41101	SPAN calibration value				

4 The settings marked in grey are not available.



EXCELL®

EXCELL PRECISION CO. LTD.

## APPENDIX VI MODBUS DATA ADDRESS TABLE

(For Hitech and Pro-face Human Machine Interface)

Data Register		Bit I/O			Bit I/O		
Modbus	SCALE	Modbus	SCALE	Output	Modbus	SCALE	Input
40001 ~ 40002	As display value	00001		Stable status	01001		Zero
40003 ~ 40004	Gross weight	00002		Zero status	01002		Clear zero compensation
40005 ~ 40006	Net weight	00003		Gross	01003		Tare
40007 ~ 40008	Tare value	00004		Net	01004		Clear tare
40009 ~ 40010	Gross weight hold value				01005		Clear pre-tare
40011 ~ 40012	Net weight hold value	00051		Zero Band	01006		Display the gross weight on main display
40013 ~ 40014	Weight final value	00052		Sp1	01007		Display the net weight on main display
40015 ~ 40016	Unit weight	00053		Sp2	01008		Enter/Exit the function mode
40017 ~ 40018	Percentage value	00054		Sp3	01009 ~ 01028		Switch from the 1 <sup>st</sup> to 20 <sup>th</sup> unit
40019 ~ 40020	Totalised value	00055		Batch Finish			
40021 ~ 40022	Totalised times	00056		Under	01050		Switch the operation modes
40023 ~ 40024	Totalised times of HI value	00057		Over	01051		Totalised the current net weight and add 1 to the totalised times
40025 ~ 40026	Totalised times of LO value	00058		Discharging	01052		Deduct the last totalised value and deduct 1 to the totalised times
40027 ~ 40028	Totalised times of OK value	00059		Hi-Hi	01053		Clear the totalised value and times
		00060		Hi	01054		Running
		00061		Go	01055		Stop
		00062		Lo	01056		Discharge starts
41001 ~ 41002	Pre-tare value	00063		Lo-Lo	01057		Hold mode ON/OFF
41003 ~ 41004	Zero band value	00064		Peak ready	01058		Release "Hold value"
41005 ~ 41006	Target value	00065		Running	01059		Output judgement
41007 ~ 41008	SP1 value	00066		ZERO calibration	01060		ZERO calibration
41009 ~ 41010	SP2 value	00067		SPAN calibration	01061		SPAN calibration
41011 ~ 41012	SP3 value	00068		Calibrate ERR0			
41013 ~ 41014	LO_LO value	00069		Calibrate ERR2			
41015 ~ 41016	LO value	00070		Calibrate ERR6			
41017 ~ 41018	HI_HI value						
41019 ~ 41020	HI value						
41021 ~ 41022	Under value						
41023 ~ 41024	Over value						
41025 ~ 41026	Peak value setting						
41101 ~ 41102	SPAN calibration value						

4 The settings marked in grey are not available.